



# Wine Chiller

**Safety Instructions** ..... 2, 3

**Installation Instructions** ..... 4

**Operating Instructions**  
Control Settings ..... 5, 6


**Care and Cleaning** ..... 7, 8

**Troubleshooting Tips** ..... 9, 10

**Consumer Support**  
Product Registration ..... 11  
Warranty ..... 13  
Consumer Support ..... 14

**Owner's Manual  
and Installation**

PXR03



**Write the model and serial numbers here:**

**Model #** \_\_\_\_\_

**Serial #** \_\_\_\_\_

Find these numbers on the Rating Plate located either inside the or outside on the rear wall of the Wine Chiller.



# IMPORTANT SAFETY INFORMATION. READ ALL INSTRUCTIONS BEFORE USING.

## ⚠️ WARNING!

Use this appliance only for its intended purpose as described in this Owner's Manual.




## SAFETY PRECAUTIONS

When using electrical appliances, basic safety precautions should be followed, including the following:

- This wine chiller must be properly installed and located in accordance with these instructions before it is used.
  - Do not allow children to climb, stand or hang on the shelves in the wine chiller. They could damage the wine chiller and seriously injure themselves.
  - Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
  - Keep fingers out of the "pinch point" areas; clearances between the doors and between the doors and cabinet are necessarily small. Be careful closing doors when children are in the area.
  - Unplug the wine chiller before cleaning and making repairs.
- NOTE:** We strongly recommend that any servicing be performed by a qualified individual.
- Do not store or install this appliance outdoors.

## ⚠️ DANGER! RISK OF CHILD ENTRAPMENT

### PROPER DISPOSAL OF THE WINE CHILLER



Child entrapment and suffocation are not problems of the past. Junked or abandoned refrigeration products are still dangerous... even if they will sit for "just a few days." If you are getting rid of your old appliance, please follow the instructions below to help prevent accidents.

#### **Before You Throw Away Your Old Refrigeration Product:**

- Take off the doors.
- Leave the shelves in place so that children may not easily climb inside.

#### **CFC Disposal**

Your old refrigerator has a cooling system that used CFCs (chlorofluorocarbons). CFCs are believed to harm stratospheric ozone.

If you are throwing away your old refrigerator, make sure the CFC refrigerant is removed for proper disposal by a qualified servicer. If you intentionally release this CFC refrigerant, you can be subject to fines and imprisonment under provisions of environmental legislation.

## USE OF EXTENSION CORDS



Because of potential safety hazards under certain conditions, we strongly recommend against the use of an extension cord.

However, if you must use an extension cord, it is absolutely necessary that it be CSA certified, 3-wire grounding type appliance extension cord having a grounding type plug and outlet and that the electrical rating of the cord be 15 amperes (minimum) and 120 volts.



## HOW TO CONNECT ELECTRICITY

*Do not, under any circumstances, cut or remove the third (ground) prong from the power cord. For personal safety, this appliance must be properly grounded.*

The power cord of this appliance is equipped with a 3-prong (grounding) plug which mates with a standard 3-prong (grounding) wall outlet to minimize the possibility of electric shock hazard from this appliance.

Have the wall outlet and circuit checked by a qualified electrician to make sure the outlet is properly grounded.

If you have only a standard 2-prong wall outlet, it is your personal responsibility and obligation to have it replaced with a properly grounded 3-prong wall outlet.

The wine chiller should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating plate.

This provides the best performance and also prevents overloading house wiring circuits which could cause a fire hazard from overheated wires.

Never unplug your wine chiller by pulling on the power cord. Always grip plug firmly and pull straight out from the outlet.

Repair or replace immediately all power cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either end.

When moving the wine chiller away from the wall, be careful not to roll over or damage the power cord.



## USE OF ADAPTER PLUGS

**Adapter plugs are not permitted in Canada.**



**READ AND FOLLOW THIS SAFETY INFORMATION CAREFULLY.  
SAVE THESE INSTRUCTIONS**

## Installing the wine chiller.

### Removing the Packaging

Before using the wine chiller, be sure all packing materials and tape have been removed, including any protective film covering the control and any film protecting the cabinet.


If you are discarding an old refrigeration product, remove the doors to reduce the danger of children being trapped inside.

### Installation Guidelines

- The wine chiller must be freestanding.
- Allow the following clearances for ease of installation, proper air circulation and electrical connections:
 

Each side	2" (51 mm)
Top	2" (51 mm)
Back	3" (51 mm)
- Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- Do not install the wine chiller where the temperature will go below 55°F (13°C) or above 90°F (32°C).
- Install it on a level floor.
- Do not install the wine chiller where it will be subject to direct sunlight, heat or moisture.
- Do not store or install this appliance outdoors.
- The following models must be installed on the floor: GWS04, GCS04.

### Leveling Legs



To raise the wine chiller

**Adjustable legs** at the front corners of the wine chiller should be set so the wine chiller is firmly positioned on the floor, with a 1/8" (3 mm) tilt to the back to help the door closure.

To adjust the leveling legs, turn the legs **clockwise to raise** the wine chiller, **counterclockwise to lower** it.

### Interior Light (available on some Models)

You can turn the light ON or OFF by pushing the light switch located on the right side of the control panel housing. If the interior light is left on, the temperature will be higher.


### Loading the Wine

As with any refrigeration product, there is a slight temperature variance at different locations within each compartment. The lower shelves provide a slightly cooler temperature than the upper shelves.



## Setting the Temperature Control

### Display Panel



### When the Wine Chiller is Plugged In

After plugging in the wine chiller and making your temperature selection, allow the wine chiller to reach the set temperature before loading your wine. This may take up to 12 hours to completely stabilize.

After loading the wine, you may notice a rise in the temperature. Allow adequate time for the temperature to return back to the set temperature. This may take up to 12 hours to completely stabilize.

- When first powering on, the display screen gives a full display for 3 seconds and the start-up sound rings; then the machine enters into operation in the locked state. See below for unlocking instructions.
- If there is no key operation for 30 seconds, the display screen will turn off. The display screen will turn on again, if you touch any key.
- When powering on, the temperature of the upper chamber will be adjusted according to the factory pre-set. By pressing the **Option** key , the

temperature area will be switched between upper chamber and lower chamber. Once a chamber is selected, the display will flash and at this time the temperature of the chamber can be set up. After locking, temperature display stops flashing.

- By selecting the key , the temperature display of upper or lower chamber flashes.
- By pressing the **Temperature-rise** key , the temperature will increase 1°C (or °F). After locking, the cooler will operate according to the setting temperature;
- By pressing the **Temperature-drop** key , the temperature will decrease 1°C (or °F). After locking, the cooler will operate according to the setting temperature
- The wine cooler's temperature can be set between 7~18°C (44~65°F).

### Switching of the Fahrenheit temperature and Celsius temperature

- Press the **Temperature-rise** key  and the **Temperature-drop** key  at the same time for 3 seconds to switch between Celsius

temperature and Fahrenheit temperature; the screen will display the Fahrenheit temperature or Celsius temperature under the current mode.

### Lock/Unlock Key Button

- By pressing the **Lock/Unlock** key  for 3 seconds, the buzzer rings and the locked mode is activated; the temperature display areas (digit display areas) of upper chamber and lower chamber turn off.
- By pressing the **Lock/Unlock** key  for 3 seconds in the locked mode, the buzzer rings and the locked mode is de-activated; After unlocking, the temperature display area of selected chamber turns on.

- When in the locked mode, if you touch any key besides the **Light** key , the display screen will keep flashing for 2.5 seconds and the buzzer will ring, alerting you to unlock the control.

**NOTE: WHEN USING ANY COMPARTMENT FOR BOTH WINE AND BEER STORAGE WE RECOMMEND THAT YOU PLACE RED WINE BOTTLES ON TOP SHELF AND BEER ON BOTTOM SHELF.**

## About the controls and settings.

### Interior Light

- After the power is on for 3 seconds, the lighting turns on by default for 30 seconds. If the lighting key is not operated within 30 seconds, the lighting will automatically turn off.
- Press the **Lighting** mode key  to turn on or turn off the light.

### Important:

- In order to extend the compressor life, please restart wine cooler after waiting 3 minutes.
- **Memory Function:**  
The cooler has a power off memory function. When power comes on again, the wine cooler will operate according to the setting mode before the power went off.
- **Fault Indication:**  
If the codes in the following table are displayed on the display area, it means the cooler has the faults indicated.

Fault code	Fault Description
Upper chamber display E1	The fault of temperature sensor of upper chamber
Lower chamber display E1	The fault of temperature sensor of lower chamber
Upper chamber display E4	The fault of defrosting sensor of upper chamber
Lower chamber display E4	The fault of defrosting sensor of lower chamber
Upper chamber display E6	Communication fault

Call for service if any of the above error messages show.

You should touch the temperature control panel softly as the panel is touch screen control. Please protect the touch control panel carefully to avoid scratching, keep far away from strong magnetic fields and high humidity, or it can cause wine cooler to not work properly.

## Cleaning the Outside

**IMPORTANT: Unplug the wine chiller before cleaning.**

**Keep the outside clean.** The cabinet can be washed with mild soap and water. Rinse thoroughly with clear water.

Never use abrasive scouring powders.

Use a glass cleaner or mild soap and water and a soft cloth to clean the glass door. Do not use any abrasive powders.

Wipe the control panel with a damp cloth. Dry thoroughly. Do not use cleaning sprays, large amounts of soap and water, abrasives or sharp objects on the panel—they can damage it. Some paper towels can also scratch the control panel.

*Do not wipe the wine chiller with a soiled dishcloth or towel. These may leave a residue that can erode the paint. Do not use scouring pads, powdered cleaners, bleach or cleaners containing bleach because these products can scratch and weaken the paint finish.*

**Stainless steel.** Regularly clean and polish the stainless steel areas (on some models) with a commercially available stainless steel cleaner such as *Gleem-it*® to preserve and protect the fine finish. *Gleem-it*® is available at leading hardware stores. It is also available through our website, GEAppliances.ca, or call 1.888.261.3055. Order part number WX10X15.

Do not use appliance wax or polish on the stainless steel.

**Protect the paint finish.** The finish on the outside of the wine chiller is a high-quality, baked-on paint finish. With proper care, it will stay new-looking and rust-free for years. Apply a coat of kitchen/appliance wax when the wine chiller is new, and then at least twice a year.

## Cleaning the Inside

**IMPORTANT: Unplug the wine chiller before cleaning.**

To clean the inner liner and racks, use a warm water and baking soda solution—about one tablespoon (15 mL) of baking soda to a quart (1 liter) of water. This both cleans and neutralizes odors. Rinse and wipe dry.

The vinyl door gasket may be cleaned with mild soap and water or a baking soda solution. Rinse well.

**Do not use detergents, scouring powders, spray cleaners or other harsh chemicals to clean the interior.**

## Defrosting

*Defrost whenever frost on the inside surfaces of the storage area becomes 1/8" (3 mm) thick.*

**Never use a heater of any kind, scraper or sharp instrument to remove frost as it may damage the wine chiller.**

**To defrost,** unplug the wine chiller. Remove the contents and wipe inside surfaces and

racks with a clean towel. If frost does not come off easily, allow the frost to melt somewhat and wipe off.

**After defrosting,** make sure inside surfaces are dry; then return the contents to the wine chiller and set the temperature control to the desired setting.

## In the Event of a Power Failure

If the power fails, open the door as infrequently as possible to maintain the temperature. A gradual rise in temperature should not have any adverse effect on the wine.

If it is extremely hot, you may want to unload the wine from the wine chiller and move the wine to a cooler location until power is restored.

When power is restored, the controls automatically are set to the **Factory Setting** 50°F (10°C). If needed, reset the controls to the desired setting.

## Care and cleaning.

---

### Vacation Time

- **Short vacations:** Leave the Wine/Beverage Cooler operating during vacations of less than three weeks.
- **Long vacations:** If the appliance will not be used for several months, remove

all items and unplug the power cord. Clean and dry the interior thoroughly. To prevent odor and mold growth, leave the door open slightly; blocking it open if necessary.

---

### Preparing to Move

Unload the wine, then secure the racks and door by taping them in place to prevent damage.

*Be sure the wine chiller stays in an upright position during the move.*

Turn the adjustable leveling legs up to the base to avoid damage.

---

### Energy Saving Tips

- The Wine/Beverage Cooler should be located in the coolest area of the room, away from heat producing appliances, and out of the direct sunlight.
- Try not to open the door too often, especially when the weather is wet or hot. Once you open the door, mind to close it as soon as possible.
- This appliance is intended to be used exclusively for the storage wine.
- Every now and then check if the appliance is sufficiently ventilated (adequate air circulation behind the appliance).
- For wine storage appliances, please arrange the temperature following the instruction: SPARKLE: 41-45°F (5-7°C), WHITE: 46-54°F (8-12°C), RED: 55-65°F (13-18°C).

## LED Refrigerator Lights

---

An authorized technician will need to replace the LED light



**Troubleshooting Tips**  
 Save time and money! Review the charts on the following pages first and you may not need to call for service.

Problem	Possible Causes	What To Do
Wine chiller does not operate and the display is blank	Wine chiller is unplugged.	• Push the plug completely into the outlet.
	The circuit breaker is tripped/ the fuse is blown.	• Replace fuse or reset the breaker.
Vibration or rattling (slight vibration is normal)	Wine chiller is on an uneven surface.	• See the <i>Leveling Legs</i> section.
The Wine/Beverage Cooler seems to make too much noise.	The rattling noise may come from the flow of the refrigerant, which is normal.	
	As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your Wine/ Beverage Cooler.	
	Contraction and expansion of the inside walls may cause popping and crackling noises.	
	The Wine/Beverage Cooler is not level.	
Motor operates for long periods or cycles	Normal when wine chiller is first plugged in.	• Wait 12 hours for the wine chiller to completely cool down.
	Often occurs when large amounts of wine are placed in wine chiller.	• This is normal.
	Door left open.	• Door is not self-closing. Always make sure that the door is closed after opening. • Check to see if a bottle is holding door open.
	Hot weather or frequent door openings.	• This is normal.
	Temperature control set at the coldest setting.	• See <i>About the control and settings</i> .
	Wine chiller is too close to the wall.	• See the <i>Installation Guidelines</i> section for the correct clearances.
	Wine chiller too warm	Normal when wine chiller is first plugged in.
Often occurs when large amounts of wine are placed in wine chiller.		• This is normal.
Temperature control not set cold enough.		• See <i>About the control and settings</i> .
Warm weather or frequent door openings.		• Set the temperature control one step colder. See <i>About the control and settings</i> .
Wine chiller is too close to the wall.		• See the <i>Installation Guidelines</i> section for the correct clearances.

## Before you call for service...

	<b>Problem</b>	<b>Possible Causes</b>	<b>What To Do</b>
Safety Instructions	Wine chiller too warm	Door left open.	<ul style="list-style-type: none"> <li>• Door is not self-closing. Always make sure that the door is closed after opening.</li> <li>• Check to see if a bottle is holding door open.</li> </ul>
		If the temperature setting is not showing what you last selected, a power outage may have occurred.	<ul style="list-style-type: none"> <li>• When the power came back on, the wine chiller returned to the default setting, which is <b>50°F (10°C)</b>. Reset the control to the desired setting.</li> </ul>
Installation Instructions	Wine chiller has odor	Interior needs cleaning.	<ul style="list-style-type: none"> <li>• See <i>Care and cleaning</i>.</li> </ul>
	Moisture forms on outside of wine chiller	Not unusual during periods of high humidity.	<ul style="list-style-type: none"> <li>• Wipe surface dry.</li> </ul>
	Moisture collects inside (in humid weather, air carries moisture into wine chiller when door is opened)	Too frequent or too long door openings.	<ul style="list-style-type: none"> <li>• Reposition bottles.</li> </ul>
Operating Instructions	Frost forms on interior surfaces of wine chiller	This is normal.	<ul style="list-style-type: none"> <li>• See the <i>Defrosting</i> section.</li> </ul>
		Door left open.	<ul style="list-style-type: none"> <li>• Excessive frost may form if the door is left open. See the <i>Defrosting</i> section.</li> <li>• Door is not self-closing. Always make sure that the door is closed after opening.</li> <li>• Check to see if a bottle is holding door open.</li> </ul>
Care and Cleaning	Wine chiller too cold	Temperature control is set too cold.	<ul style="list-style-type: none"> <li>• See <i>About the control and settings</i>.</li> </ul>
		If the temperature setting is not showing what you last selected, a power outage may have occurred.	<ul style="list-style-type: none"> <li>• When the power came back on, the wine chiller returned to the default setting, which is <b>50°F (10°C)</b>. Reset the control to the desired setting.</li> </ul>
		The room temperature where the wine chiller is located is too cold.	<ul style="list-style-type: none"> <li>• For proper operation, the room temperature should be equal to or greater than the set temperature of the wine chiller.</li> </ul>
Troubleshooting Tips	Temperature in the display is not the temperature that was just set.	This is normal.	<ul style="list-style-type: none"> <li>• After you set the temperature, the display will go back to showing the actual temperature.</li> </ul>
	Condensation on front of door	Wine chiller is located in a high humidity environment.	<ul style="list-style-type: none"> <li>• Wipe off the condensation with a clean, dry cloth.</li> <li>• Locate the wine chiller in a lower humidity environment.</li> </ul>
	Water on floor behind wine chiller	Door left open.	<ul style="list-style-type: none"> <li>• Door is not self-closing. Always make sure that the door is closed after opening.</li> <li>• Check to see if a bottle is holding door open.</li> </ul>
Consumer Support	The door will not close properly	The Wine/Beverage Cooler is not level.	
		The door was reversed and not properly installed.	
		The gasket is dirty.	
		The shelves are out of position.	

---

Please place in envelope and mail to:  
Veuillez mettre dans une enveloppe et envoyez à :

**OWNERSHIP REGISTRATION  
P.O. BOX 1780  
MISSISSAUGA, ONTARIO  
L4Y 4G1**

**(FOR CANADIAN CONSUMERS ONLY -  
POUR RÉSIDENTS CANADIENS SEULEMENT)**

---



For Canadian  
Customers



Pour les  
consommateurs  
canadiens

CUT ALONG THIS LINE AND RETURN CARD – THANKS  
DÉCOUPEZ ICI ET ENVOYEZ LA FICHE – MERCI

### OWNERSHIP REGISTRATION CERTIFICATE – FICHE D'INSCRIPTION DU PROPRIÉTAIRE

Please register your product to enable us to contact you in the remote event a safety notice is issued for this product and to allow for efficient communication under the terms of our warranty, should the need arise.

Veillez enregistrer votre produit afin de nous permettre de communiquer avec vous si jamais un avis de sécurité concernant ce produit était émis et de communiquer facilement avec vous en vertu de votre garantie, si le besoin s'en fait sentir.

REGISTER ON-LINE: ENREGISTREMENT SUR INTERNET À :		<b>www.geappliances.ca</b>		MAIL TO:	<b>P.O. BOX 1780, MISSISSAUGA</b>
		<b>www.electromenagersge.ca</b>		POSTEZ À :	<b>ONTARIO, L4Y 4G1</b>
<input type="checkbox"/> MR. / M.	<input type="checkbox"/> MRS. / MME	FIRST NAME / PRÉNOM		LAST NAME / NOM	
<input type="checkbox"/> MISS/MLE	<input type="checkbox"/> MS.				
STREET NO / N° RUE		STREET NAME / RUE			APT.NO/APP./RR#
CITY / VILLE				PROVINCE	POSTAL CODE/CODE POSTAL
AREA CODE/IND. RÉG.	TELEPHONE/TÉLÉPHONE		E-MAIL/COURRIEL		
DID YOU PURCHASE A SERVICE CONTRACT FOR THIS APPLIANCE? AVEZ-VOUS ACHETÉ UN CONTRAT DE SERVICE POUR CET APPAREIL ?			YES/OUI	<input type="checkbox"/>	IF YES/SI OUI : EXPIRATION
			NO/NON	<input type="checkbox"/>	Y/A M DU
NAME OF SELLING DEALER / NOM DU MARCHAND				MODEL / MODÈLE	
INSTALLATION DATE / DATE D'INSTALLATION Y/A M DU		CORRESPONDENCE CORRESPONDANCE	<input type="checkbox"/> ENGLISH <input type="checkbox"/> FRANÇAIS	SERIAL / SÉRIE	
<input type="checkbox"/> I do not wish to receive any promotional offers regarding this product. Je ne désire pas recevoir d'offres promotionnelles concernant ce produit.					

# Wine Chiller Warranty.

GEAppliances.ca



All warranty service provided by our Factory Service Centers, or an authorized Customer Care® technician. For service call 1-800-561-3344.

**Proof of the original purchase date is needed to obtain service under warranty.**

## For The Period Of: Mabe Will Replace:

### One Year

From the date of the original purchase

**Any part** of the wine chiller which fails due to a defect in materials or workmanship. During this **limited one-year warranty**, Mabe will also provide, **free of charge**, all labour and service to replace the defective part.

## What Mabe Will Not Cover:

- Service trips to your home to teach you how to use the product.
- Improper installation.
- Failure of the product if it is abused, misused, or used for other than the intended purpose or used commercially.
- Loss of wine due to spoilage.
- Replacement of house fuses or resetting of circuit breakers
- Damage to the product caused by accident, fire, floods or acts of God.

■ In-home warranty service will be provided in areas where it is available and deemed reasonable by Mabe to provide.

■ Incidental or consequential damage to personal property caused by possible defects with this appliance.

### **Please read your Use & Care Material:**

If you then have any questions about operating the product, please contact your dealer or our Consumer Affairs office at the address below, or call toll free:  
MC Commercial Inc.  
1-800-561-3344  
Consumer Information Service

*This warranty is extended to the original purchaser and any succeeding owner for products purchased in Canada for home use within Canada. If the product is located in an area where service by a Mabe Authorized Servicer is not available, you may be responsible for a trip charge or you may be required to bring the product to an Authorized Mabe Service location.*

*Some provinces do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from province to province. To know what your legal rights are in your province, consult your local or provincial consumer affairs office.*

**Warrantor: MC Commercial Inc.**

*If further help is needed concerning this warranty, write;*

*Consumer Relations Manager - MC Commercial Inc.*

*1 Factory Lane, Suite 310, Moncton NB E1C 9M3*

Safety Instructions

Installation Instructions

Operating Instructions

Care and Cleaning

Troubleshooting Tips

Consumer Support

## Service Telephone Numbers

---



### *In-Home Repair Service 1-800-561-3344*

---

Expert Mabe repair service is only a phone call away.



### *Parts and Accessories 1-800-263-0686*

---

Individuals qualified to service their own appliances can have parts or accessories sent directly to their homes.

*Instructions contained in this manual cover procedures to be performed by any user. Other servicing generally should be referred to qualified service personnel. Caution must be exercised, since improper servicing may cause unsafe operation.*



### *Service Satisfaction*

---

If you are not satisfied with the service you receive from Mabe, follow these steps. First, contact the people who serviced your appliance. Next, if you are still not pleased, write all the details—including your phone number—to:

Manager, Consumer Relations,  
MC Commercial Inc., Suite 310, 1 Factory Lane,  
Moncton (N.-B.) E1C 9M3