

# INSTALLATION INSTRUCTIONS

**Install Damper, spacer, and reducer on top of the 6" duct exit.**  
**Tape all parts together and connect 5" round ductwork**

