

Installation Instructions

Stainless Steel Tubular Handle Kit ZTB700



BEFORE YOU BEGIN

Read these instructions completely and carefully.

IMPORTANT: Save these instructions for local inspector's use.

IMPORTANT: OBSERVE ALL GOVERNING CODES AND ORDINANCES.

NOTE TO INSTALLER: Be sure to leave these instructions with the Consumer.

NOTE TO CONSUMER: Keep these instructions with your Owner's Manual for future reference.

This kit provides a stainless steel tubular handle to coordinate with other Monogram appliances.

- The tubular handle must be installed onto the custom wood panel before it is secured to the dishwasher door.
- Prepare the custom panel by following the Installation Instructions shown on the custom panel template.



WARNING:

To prevent electric shock, disconnect electrical power supply to the dishwasher.



CAUTION:

When the dishwasher is pulled out of the enclosure, it can tip over when the door is opened. Use caution to prevent personal injury or damage to the dishwasher.

Tools and Materials Required:

- Gloves to protect against sharp edges
- Phillips screwdriver
- Drill and appropriate bits

This Kit Includes:

- Tubular handle
- 2 Mounting screws
- 1 Paper instruction

INSTALL TUBULAR HANDLE

The handle should be positioned on the custom panel, approximately 4-1/2" from the top of the panel. Measure adjacent cabinet hardware position to be sure the handle is aligned accurately.

- Locate the vertical center of the panel and draw a pencil line.
- Measure and pencil a centerline mark on the handle. Use the handle as a template to locate and mark the exact position of the screwholes.
- Drill 3/32" pilot holes. Drive screws from the back side of the panel into the handle.

