

INSTALLATION INSTRUCTIONS

356NDK DUCTLESS CONVERSION KIT FOR THRU SOFFIT VENTING FOR USE WITH PM250 POWER MODULE

1. Install PM250 per installation instructions shipped with power module.
2. Remove aluminum filter and replace with combination filter furnished with kit and aluminum filter that was removed.
3. Locate front soffit cutout by determining centerline of hood for vertical centerline and 25" from top of hood liner for horizontal centerline.
4. Layout a 4" vertical, 10" horizontal pattern and cut opening in soffit.
5. If bottom of soffit is covered, cut hole to allow insertion of 7" round to 4" x 10" angle boot furnished with kit.
6. Insert 90 degree angle boot into 7" pipe then insert boot into soffit and align with Cutout. Place 7" pipe on unit's outlet.
7. Tape joint and seal around pipe to prevent air leaks.
8. Install grille (included) over soffit cutout.

