

### TEMPLATE 1

### TEMPLATE 2 - THIS SIDE IS FOR BOTTOM OF THE CABINET


**IMPORTANT**  
 Read the instruction booklet for complete instructions before beginning installation.  
 Template must lay flat against the cabinet when locating the holes.

### INSTRUCTIONS

(See installation booklet for complete instructions)

If you drill the 4 mounting holes from the bottom side of the cabinet—measure the thickness of the front rail and cut that amount off the front of the template. Use the cutting lines to insure a straight cut. Place the cut edge against the back side of the front rail and position. Drill the 4 holes 1/4" DIA. as described in the installation instruction booklet.

**IMPORTANT**  
 MAKE SURE THAT THE LEFT AND RIGHT SIDES OF THIS TEMPLATE—MICROWAVE SIDE (A) OR (B)—AGREE WITH THE EVENTUAL DESIRED LOCATION OF THE MOUNTED OVEN. DEPENDING ON WHETHER YOU CHOOSE TO DRILL FROM INSIDE THE CABINET (A) OR FROM THE BOTTOM SIDE OF THE CABINET (B), THE TEMPLATE SIDES MARKED "MICROWAVE SIDE (A)" OR "MICROWAVE SIDE (B)" WILL INDICATE THE LOCATION OF THE SIDES OF THE MOUNTED OVEN.



MICROWAVE FRONT CONTROL PANEL SIDE

MICROWAVE FRONT DOOR SIDE

