



27" AND/Y/ET 30" ONLY/SOLAMENTE/SEULEMENT

COLORS / COLOR / COULEURS

- BK- BLACK/NEGRO/NOIR
- W- WHITE/BLANCO/BLANC
- O- ORANGE/NARANJA/ORANGE
- BR-BROWN/MORENO/BRUN
- PK-PINK/ROSA/ROSE
- V- VIOLET/VIOLETA/VIOLET
- G- GREEN/VERDE/VERT
- R- RED/ROJO/ROUGE
- Y- YELLOW/AMARILLO/JAUNE
- BL- BLUE/AZUL/BLEU
- BR/W-BROWN/WHITE // MORENO/BLANCO // BRUN/BLANC
- BL/W-BLUE/WHITE // AZUL/BLANCO // BLEU/BLANC

CODE	GAUGE/MED. CALIBRE	TEMP. °C	STYLE CSA	UL
1	18	125	CL1251	3173
2	16	125	CL1251	3173
3	14	125	CL1251	3173
4	12	125	CL1251	3173
5	18	SEE NOTE/VEA LA NOTA/VOIR NOTE		
6	16	SEE NOTE/VEA LA NOTA/VOIR NOTE		
7	14	150	EXL-150	3321
8	12	150	EXL-150	3321
9	10	150	EXL-150	3321
10	18	200	SEW-1	3122
11	16	200	SEW-1	3122
12	12	250		3252
13	16	250		3252
14	20	SEE NOTE/VEA LA NOTA/VOIR NOTE		
15	8	150	EXL-150	3321
16	8	60		
17	10	60		

NOTE
 WIRES 200°C UL 3122 FOR 24" MODELS
 Wires 150°C UL 3321 FOR 27" AND 30" MODELS
NOTA
 ALAMBRE 200°C UL 3122 PARA MODELOS 24"
 ALAMBRE 150°C UL 3122 PARA MODELOS 27" Y 30"
NOTE
 FILS 200°C UL 3122 POUR LE MODELE 24"
 FILS 150°C UL 3321 POUR LES MODELES 27" ET 30"



CAUTION: DISCONNECT POWER BEFORE SERVICING UNIT.
ATENCIÓN: CORTAR EL CORRIENTE ANTES DE REALIZAR EL MANTENIMIENTO DEL ELECTRODOMESTICO.
ATTENTION: COUPEZ L'ALIMENTATION AVANT D'EFFECTUER LA REPARATION.