

Undercounter Dishwasher

PRODUCT MODEL NUMBERS

MDB7609AW	MDB7809AW
MDB7709AW	MDB8859AW
MDB7749AW	MDB8949SA
MDB7749BW	MDB8949SB
MDB7749SA	MDB8959AW
MDB7749SB	MDB8959SA
MDB7759AW	MDB8959SB
MDB7759SA	MDBH979AW
MDB7760AW	MDBH979SA
MDB7760SA	MDBH989AW

Electrical Requirements: 120-volt, 60-Hz, AC-only, 15- or 20-amp. fuesd electrical supply. Copper wire only. A timedelay fuse or circuit breaker and separate circuit is recommended.

If direct wiring dishwasher: Use flexible, armored or


nonmetallic, sheathed copper wire with grounding wire that meets the wiring requirements for

your home and local codes and ordinances.

Use a U.L.-listed or CSA-approved conduit connector.

If connecting dishwasher with a power supply cord:

Use Power Supply Cord Kit (Part No. 4317824) marked for use with dishwashers. Follow the kit



Power supply cord must plug into a grounded three-prong, outlet, located in the cabinet next to the dishwasher opening. Outlet must meet all local codes and ordinances.



Water Supply Requirements: A hot water line with 20 to 120 psi (138 to 862 kPa) water pressure. Water temperature must be 120°F (49°C) water at dishwasher. Use 3/8" O.D. copper tubing with compression fitting or flexible braided water supply line (1/2" minimum plastic tubing is not recommended). Use a 90° elbow with 3/4" N.P.T. external pipe threads on one end. Do not solder within 6" (15.2 cm) from water inlet valve.

Drain Requirements: A new drain hose is supplied with your dishwasher. If this is not long enough, use a new drain hose with a maximum length of 12' (3.7 m) (Part No. 3385556) that meets all current AHAM/IAPMO test standards, is resistant to heat and detergent, and fits the 1" (2.5 cm) drain connector of the dishwasher.

Make sure to connect the drain hose to waste tee or disposer inlet above drain trap in house plumbing and 20" (50.8 cm) minimum above the floor. It is recommended




that the drain hose either be looped up and securely fastened to the underside of the counter, or be connected to an air gap.

Make sure to use an air gap if the drain hose is connected to house plumbing lower than 20" (50.8 cm) above subfloor or

Use ½" (1.3 cm) minimum I.D. drain line fittings. If required, the air gap should be installed in accordance with the air gap installation instructions. When connecting the air gap a rubber hose (not provided) will be needed to connect to the waste tee or disposer inlet.

PRODUCT DIMENSIONS



NOTE: Shaded areas of cabinet walls show where utility connections may be installed.

- *Measured from the lowest point on the underside of the countertop. May be reduced to 337/s" (86 cm) by removing wheels from dishwasher, or 333/4" (85.7 cm) by removing wheels AND perforated section in the insulation blanket.
- **Minimum, measured from narrowest point of opening.

