



27" BUILT-IN ELECTRIC SINGLE OVEN


MODELS:

WOS72EC7HB01 (Black)

WOS72EC7HS01 (Stainless)

WOS72EC7HV01 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3		Skin, Control Panel	12	W10904157	Chassis, Cover Top Back 27"
	W11129956	Instructions, Installation		W11026968	Black	13	W10864102	Tray, Electronic
	W11097840	Instructions, Undercounter Installation		W10899876	Stainless	14	W10655465	Chassis, Back Divider
	W11220323	Guide, Use & Care	4	W11253186	Appliance Manager, Copernicus (With Power Supply)	FOLLOWING PARTS NOT ILLUSTRATED		
	W11097305	Guide, Internet Connectivity	5	W11200129	Blower			
	W11046178	Sheet, Tech	6	W10318193	Chassis, Cover Top Front 27"	W11225368		Harness, Main
W11046185	Diagram, Wiring	7	W11162062	Gasket, Rubber	W11225369		Harness, Signal	
2		Assembly, Control Panel (Includes Overlay)	8	7101P426-60	Screw	W11132989		Harness, Door Latch
	W11107236	Black	9	W11234541	Antenna	W10562910		Harness, EOL
	W11107232	Stainless	10	W10655463	Bracket, Blower (Left)	W11233570		Harness, Console
	W11107252	Black Stainless		W10655462	Bracket, Blower (Right)	4448664		Clamp, Conduit
			11	W10728475	Gasket, Rubber	W10655464		Bracket, Harness
						W10487999		Clip, Harness
						4450800		Screw, Grounding
						4454842		Tie, Cable


OVEN PARTS



OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10254050	Screw	16	W10622170	Probe, Sensor	26	W10412722	Lens, Light
2	W11085298	Tube, Vent	17	W10616809	Base, Vent Exhaust	27	7101P426-60	Screw
3	W11044775	Receiver, Hinge	18	4449751	Thermostat (TOD)	28	W10412711	Bulb, Light
4	W10618102	Spacer, Base	19	W10282901	Base, Chassis	29	7101P427-60	Screw
5	W10618131	Latch, Motorized	20		Assembly, Bottom Vent	30	W10834501	Spacers, Front
6	W10904159	Chassis, Top		W10327375	Black	31	W10318196	Duct, Chassis Back
7	W10734063	Assembly, Light		W10351280	Stainless	32	8285593	Cover, Connector
8	W10618101	Foot, Base		W10869573	Black Stainless	33		Trim, Side
9	W10904163	Deflector, Blower		W10283008	Chassis, Bottom Duct		W10344481	Black (Left)
10	W10283037	Vent, Top 27"	21		Trim, Bottom Vent		W10344480	Black (Right)
11	W10282961	Gasket	22		Black	34	W10834286	Spacer, Center
12	W10616810	Cover, Vent Exhaust		W10351237	Black	35	W11045086	Receiver, Slow Close Hinge
13	W10663556	Side, Chassis (Left)		W10327378	Stainless	36	W11034940	Shield, Slow Close Hinge
	W10318190	Side, Chassis (Right)	23	W10921376	Black Stainless			FOLLOWING PARTS NOT ILLUSTRATED
14	W10904162	Back, Chassis	24	W10213759	Support, Air Channel		W10520716	Insulation, Wrap
15		Liner, Oven (Not Serviceable)	25	W10351308	Spacer, Chassis Bottom Duct		W10282945	Insulation, Back
				W10351278	Bumper & Screw		W11112951	Insulation


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10347597	Assembly, Window Pack	7		Assembly, Door Glass	10	W10284297	Bracket, Glass
2	W10284285	Spring, Door Glass Fixation		W10866269	Black	11	W10480830	Screw
3	7101P635-60	Screw (Black)		W10866268	Stainless	12	7101P426-60	Screw
4	W10884775	Nameplate		W11028412	Black Stainless	13	7101P653-60	Screw
5	W10320793	Assembly, Liner	8		Handle, Door	14	W10653954	Clip, Spring Metal
6	W11045550	Hinge, Slow Close Door		W11022641	Black	15	3196183	Screw
				W10880280	Stainless			
				W10903344	Black Stainless			
			9	W10678525	Glass, Inner			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10260252	Element, Broil	7	W10546517	Element, Bake	13	W10720084	Screw
2	W10317431	Rack, Oven	8	W10722667	Fan, Convection	14	W10906658	Screw
3	W10318198	Tray, Hidden Bake	9	W10631504	Nut, Acorn (LH)			
4	7101P434-60	Screw	10	W10631503	Blade, Fan			
5	7101P426-60	Screw	11	W10260248	Ring, Element			
6	W10282957	Crossbar, Hidden Bake Tray	12	W10359278	Baffle, Convection			

OPTIONAL PARTS (NOT INCLUDED)

PAIN, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black

PAIN, SPRAY

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Grid, Broiler Pan and
	W10275756	Cleaner, Granite
	W10123240	Rack, Broiler Pan & Roasting
	W10355049	Wipes, Stainless Steel Cleaning
	W10355016	Cleaner, Stainless Steel
	W10745649	Rack, Sliding