




**30" BUILT-IN ELECTRIC SINGLE OVEN WITH CONVECTION
(Fingerprint Resistant)**

MODELS:

WOSA2EC0HN01 (Sunset Bronze)

WOSA2EC0HZ01 (Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	7101P427-60	Screw	14	W10655465	Chassis, Back Divider
	W11129956	Instructions, Installation	5	W11200129	Blower	15	W11162063	Gasket, Rubber
	W11097840	Instructions, Undercounter Installation	6		Skin, Control Panel			FOLLOWING PARTS NOT ILLUSTRATED
	W11220325	Guide, Use & Care		W10892169	Sunset Bronze		W11225374	Harness, Main
	W11097305	Guide, Internet Connectivity		W10893983	Stainless		W11225375	Harness, Signal
	W11108419	Sheet, Tech	7	W10318192	Chassis, Cover Top Front 30"		W11132989	Harness, Door Latch
	W11108424	Diagram, Wiring	8	7101P426-60	Screw		W10562910	Harness, EOL
2		Assembly, Control Panel (Includes Overlay)	9	W11234541	Antenna		W11233570	Harness, Console
	W11105049	Sunset Bronze	10	W10655463	Bracket, Blower (Left)		4448664	Clamp, Conduit
	W11105047	Stainless		W10655462	Bracket, Blower (Right)		W10655464	Bracket, Harness
3	W11040194	Manager, Appliance (With Power Supply)	11	W10728475	Gasket, Rubber		W10487999	Clip, Harness
			12	W10904156	Chassis, Cover Top Back 30"		4450800	Screw, Grounding
			13	W10864102	Tray, Electronic		4454842	Tie, Cable


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10254050	Screw	18	4449751	Thermostat (TOD)	32	8285593	Cover, Connector
2	W11085298	Tube, Vent	19	W10834867	Base, Chassis	33		Cover, Side Trim
3	W11044775	Receiver, Hinge	20		Assembly, Bottom Vent		W10344481	Black (Left)
4	W10618102	Spacer, Base					W10344480	Black (Right)
5	W10618131	Latch, Motorized		W10921397	Sunset Bronze	34	W10834286	Spacer, Center
6	W10904158	Top, Chassis		W10869571	Stainless	35	W11045086	Receiver, Slow Close Hinge
7	W11198684	Assembly, Oven Light	21	W10283008	Chassis, Bottom Duct			
8	W10618101	Foot, Base	22		Trim, Bottom Vent			FOLLOWING PARTS NOT ILLUSTRATED
9	W10904163	Deflector, Blower		W10921375	Sunset Bronze		W10520715	Insulation, Wrap
10	W10283036	Vent, Top 30"		W10327377	Stainless		W10282944	Insulation, Cavity
11	W10739089	Gasket	23	W10213759	Support, Air Channel		W10464568	Insulation, Control Knob
12	W10616810	Cover, Vent Exhaust	24	W10351308	Spacer, Chassis Bottom Duct			
13	W10663556	Side, Chassis (Left)	25	W10351278	Bumper & Screw			
	W10318190	Side, Chassis (Right)	26	W10472386	Lens, Light			
14	W10904160	Back, Chassis	27	7101P427-60	Screw			
15		Liner, Oven (Not Serviceable)	28	W10472384	Bulb, Light			
16	W10622170	Probe, Sensor	29	W11034940	Shield, Slow Close Hinge			
17	W10616809	Base, Vent Exhaust	30	W10834501	Spacers, Front			
			31	W10318196	Duct, Chassis Back			


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10347596	Assembly, Window Pack	6	W11045551	Hinge, Slow Close Door	9	W10618107	Glass, Inner
2	W10284285	Spring, Door Glass Fixation	7		Assembly, Door Glass	10	W10284297	Bracket, Glass
3	7101P635-60	Screw (Black)		W10866271	Sunset Bronze	11	W10480830	Screw
4	W10884775	Nameplate		W11028416	Stainless	12	7101P426-60	Screw
5	W10709147	Assembly, Liner	8		Handle, Door	13	7101P653-60	Screw
				W11176370	Stainless	14	W10653954	Clip, Spring Metal
						15	3196183	Screw

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10260252	Element, Broil	8	W10722667	Fan, Convection	16	W11033111	Nut, Locking
2	W11122597	Rack, Oven	9	W10631504	Nut, Acorn (LH)	17	9755542	Probe, Temperature
3	W10318198	Tray, Hidden Bake	10	W10631503	Blade, Fan			
4	7101P434-60	Screw	11	W10260248	Ring, Element			
5	7101P426-60	Screw	12	W10914672	Baffle, Convection			
6	W10282957	Crossbar, Hidden Bake Tray	13	W10720084	Screw			
7	W10546517	Element, Bake	14	W10906658	Screw			
			15	W10696226	Jack, Meat Probe			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black

PAINT, SPRAY

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Grid, Broiler Pan and
	W10275756	Cleaner, Granite
	W10123240	Rack, Broiler Pan & Roasting
	W10355049	Wipes, Stainless Steel Cleaning
	W10355016	Cleaner, Stainless Steel
	W10745649	Rack, Sliding