

Bosch Dishwasher Lineup

Other Design Options



Other Colour Options

White	SHE3AEM2N	SHE4AEM2N	SHX5AEM2N	SHS53C72N	N/A	SHS53CM2N	SHE53C82N	N/A	N/A	N/A	N/A	N/A	N/A
Black	SHE3AEM6N	SHE4AEM6N	SHX5AEM6N	N/A	N/A	N/A	SHE53C86N	N/A	N/A	N/A	N/A	N/A	N/A
Black Stainless	N/A	N/A	SHX5AEM4N	N/A	N/A	N/A	N/A	N/A	N/A	N/A	SHP78CM4N	N/A	N/A

	100 Series	100 Plus	100 Premium	300 Series				500 Series		800 Series		Benchmark*	
dBA	50	48	46	46	46	46	46	46	44	42	42	38	38
Wash System	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PrecisionWash*	PowerControl™	PrecisionWash*	PowerControl™
Dry System	PureDry*	PureDry*	PureDry*	PureDry*	PureDry*	PureDry*	PureDry*	PureDry*	AutoAir*	CrystalDry™	CrystalDry™	PureDry	CrystalDry™
Tub Material	Hybrid	Hybrid	Hybrid	Full Stainless	Full Stainless	Full Stainless	Full Stainless	Full Stainless	Full Stainless	Full Stainless	Full Stainless	Full Stainless	Full Stainless
"On" Notification	None	None	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*	InfoLight*
3rd Rack	None	None	Standard	None	Standard	Standard	Standard	Flexible	Flexible	Flexible	Flexible	Flexible	Flexible
Middle Rack Adjust	None	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*	RackMatic*
Tine Flexibility	None	None	None	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™	FlexSpace™
Rack Glide	None	None	None	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™	EasyGlide™
Leak Protection	24/7 Overflow Protection	24/7 Overflow Protection	24/7 Overflow Protection	24/7 AquaStop*	24/7 AquaStop* Plus	24/7 AquaStop*	24/7 AquaStop*	24/7 AquaStop*	24/7 AquaStop*	24/7 AquaStop* Plus	24/7 AquaStop*	24/7 AquaStop* Plus	24/7 AquaStop*
Wi-Fi Enabled	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect	Home Connect
Control Type	Touch Controls	Touch Controls	Touch Controls	Touch Controls	Push Buttons	Touch Controls	Touch Controls	Touch Controls	Touch Controls	Touch Controls	Touch Controls	Touch Controls	Touch Controls
Anti-Fingerprint	✓	✓	✓	✓	None	✓	✓	✓	✓	None	✓	✓	✓
Water Softener	None	None	None	None	✓	None	None	None	None	None	✓	None	✓



PureDry®
PureDry® is a closed drying system that does not pull in outside air and gently whisks moisture away from dishes as they cool. With no heating element, you can safely place plastics anywhere.



AutoAir®
When selected, the AutoAir® option automatically opens the door at the end of the drying cycle to let moisture escape and fresh air circulate for drier dishes.



CrystalDry™
Patented CrystalDry™ technology transforms moisture into heat up to 176°F to get dishes, including plastics.



PowerControl™ Spray Arm
PowerControl™ spray arm enhances PrecisionWash® performance to target your dirtiest dishes with a deeper clean, no matter where you load them on the bottom rack. No more scrubbing, pre-rinsing, or hand washing.



Not All 3rd Racks Are Equal
Bosch third racks give you the additional flexibility and 30% more loading area.*
*Compared to Bosch dishwasher with two racks.