


Frigidaire

Factory Parts Catalog



Product No.	GLEFZ389HCA
Series	30"/s elec
Color	stainless
Market	North America
Owner's Guide	316417033
Installation Instructions	316454912
Service Data Sheet	316519904

 **Electrolux**

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995515409
08/05/27
(EN/SERVICE/BJH)
369

**30-INCH FREE-
STANDING ELECTRIC
RANGE**

**Model No.
GLEFZ389H**

Copyright © 2008 Electrolux Home Products, Inc.
All rights reserved.

BACKGUARD




T20G0089

BACKGUARD

POS. NO	PART NO.	DESCRIPTION
1	316416100	Shield, backguard, rear wall
13A	316095502	Switch, infinite, warmer
14	316022500	Light/Lamp, indicator, 125 V
15	316411405	Support, backguard, black, RH
15A	316411404	Support, backguard, black, LH
19	316436259	Panel, control, brush alum
20 #	316418700	Clock/Timer, electronic, ES510
20A	316419700	Overlay, clock, black, w/mini oven, ES510
23	316419200	Bracket, clock, (2)
31	316223002	Knob, control, black
46	316437800	Lens-light/lamp, indicator, clear
54 #	316021500	Switch, infinite, small element
54A#	316021501	Switch, infinite, large element
54B#	316238200	Switch, infinite, dual
56	316234013	Shield, backguard, black, inner
69	5303288565	Screw, truss sqdr, 8-32 x 3/16, switch mtg
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021109	Screw, 8-18 x 0.5, chrome
*	316021110	Screw, 8-18 x 0.5, black


BODY



BODY

POS. NO	PART NO.	DESCRIPTION
1	316401800	Panel, main back
3	316400118	Panel, bodyside, black, RH
3	316400119	Panel, bodyside, black, LH
5	316272900	Screw, leveling, plastic, rear, (2)
5A	316498900	Leveling Leg Assy, metal, front, (2), bracket & leg
6	316496207	Rack, oven, (3)
6B	316496205	Rack, oven
8	316400601	Panel, oven bottom
8*	316064600	Support, oven bottom
8A	316411104	Base, bake element
9	316081900	Pan, broilerOPTIONAL ACCESSORY
10	316082000	Insert, broiler panOPTIONAL ACCESSORY
12	316445500	Switch, oven light, door frame
14	316116400	Receptacle, oven light
15	316538901	Lamp, oven light
16	08011086	Lens, oven light, glass
17	316087500	Retainer, lens
18 #	316405800	Latch Assembly, oven door
21	316408000	Clip, bodyside
25	316406200	Shield, heat, lower
29	316407301	Glide, drawer, front
37 #	316490000	Probe, oven temp
42	316407700	Shield, wool, lower
43	3131732	Screw, 8-18 x 1.438, oven bottom
44	316517600	Spacer, oven door
45	316234100	Shield, wire, vent tube
57	316457801	Cover, access
58	316403802	Insulation, oven sump
58A	316406600	Insulation, oven wrapper
58B	316406500	Insulation, oven back
59	316208401	Vent Tube, assembly, w/catalyst
59A	316208304	Tube, oven vent, upper
62 #	5303935271	Terminal Block Kit
62*	316001003	Screw, ground wire
62*	316205500	Nut, hex flange, 3/8 10-32
62*	316542200	Insulator
63	316542600	Plate, grounding strap
66 #	316430900	Element, broil, 4000W
67	316413800	Element, bake, hidden
68	316429100	Support, element, broil
71	316422304	Shield, rear wall
86	316441300	Receptacle, hinge
86*	316418901	Screw, trilobe, 10-32 x 5/16"
87	316081200	Bracket, cable mtg
88	316203500	Rod, auto latch
89 #	316464300	Motor-latch
106	316404100	Bracket, motor mtg.
107	316026701	Cover, fan
108#	316415800	Motor, fan
109	316136400	Blade, fan
111	316136600	Nut, fan retainer

BODY




NOTE: Oven Liner N/A
Ass. du four N/A

T20V0218A

BODY

POS. NO	PART NO.	DESCRIPTION
151	316404600	Shield, bodyside
161#	316211603	Element, convection fan, 350 W
170	316112003	Anti Tip Kit, assembly
170*	316107200	Bracket, anti-tip
170*	316112500	Template, anti-tip
170*	316116000	Screw, concrete, 1.75", anti-tip brkt
* #	316443024	Wiring Harness, main
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021110	Screw, 8-18 x 0.5, black
*	316021132	Screw, 8-18 X 11/16, black
*	316089500	Screw, 10-16 x .486
*	5303285179	Screw, wafer head, 8-32T x 0.500, black
*	5308014215	Screw, 6-20 x 0.312

TOP/DRAWER




T20T0072

TOP/DRAWER

POS. NO	PART NO.	DESCRIPTION
1	316408703	Drawer, utility
2	316403300	Liner, drawer
4	316409407	Panel, drawer front, stainless
7	316407400	Glide, drawer, rear
15 #	318178110	Element, surface, 6", 1200, (2), radiant
15A#	316465001	Element-surface, 6"/9", 3000W, dual radiant
15B#	316464901	Element-surface dual, 1700W/2700W
15D#	318198832	Element, surface, warmer, 100 W
16	316531908	Smooth, top, black
18	316436600	Hinge Bracket, maintop, (2)
26	316427600	Channel, element support, (2)
26A	316099202	Bracket, chassis support, rear
26B	316214200	Bracket, chassis support, front
39	316246100	Handle, door/drawer, stainless
52	316461700	Clip, element mtg
* #	316510608	Harness-wiring, surface
*	316468100	Cleaner, smoothtop, w/sponge
*	316001002	Screw, wafer head, 10-24 x 1.81, (2), handle mtg.
*	316021105	Screw, hex head cup pt, 8-18 x 0.375, black
*	316021109	Screw, 8-18 x 0.5, chrome
*	316021110	Screw, 8-18 x 0.5, black
*	5308014215	Screw, 6-20 x 0.312

DOOR



T20D0029

DOOR

POS. NO	PART NO.	DESCRIPTION
4	316452700	Glass, oven door, black, outer
6	316406306	Shield, wool
7	316405600	Insulation, oven door
8	316117500	Glass, oven door, heat barrier
9	316423701	Liner, oven door
10	316001002	Screw, wafer head, 10-24 x 1.81, (2), handle mtg.
10B	316008401	Washer, 3/4 OD x 1/4 ID, steel
12	316405000	Seal, oven door
13	316407911	Panel, oven door, stainless, outer
17	316402403	Spacer, door glass, (2)
20	316408600	Spacer, door handle, (2)
23	316456304	Hinge, oven door, (2)
23*	316418900	Screw, sims lp, #8-32 x 5/16", black
39	316246100	Handle, door/drawer, stainless
53	316408201	Shield, door filler, black, (2)
55	316408300	Bracket, glass support, (4)
60B	316021110	Screw, 8-18 x 0.5, black
*	316433603	Label, anti-tip
*	316021109	Screw, 8-18 x 0.5, chrome
*	5303285179	Screw, wafer head, 8-32T x 0.500, black