


COLORS / COLOR / COULEURS


- BK - BLACK/NEGRO/NOIR
- W - WHITE/BLANCO/BLANC
- O - ORANGE/NARANJA/ORANGE
- BR - BROWN/MORENO/BRUN
- PK - PINK/ROSA/ROSE
- V - VIOLET/VIOLETA/VIOLET
- G - GREEN/VERDE/VERT
- R - RED/ROJO/ROUGE
- Y - YELLOW/AMARILLO/JAUNE
- BL - BLUE/AZUL/BLEU
- BR/W - BROWN/WHITE // MORENO/BLANC // BRUN/BLANC
- BL/W - BLUE/WHITE // AZUL/BLANC // BLEU/BLANC

CODE/CODIGO/CODE

| CODE | GAUGE/MED. CALIBRE | TEMP. °C | STYLE | CSA | UL |
|------|--------------------|----------|---------|------|----|
| 1 | 18 | 125 | CL1251 | 3173 | |
| 2 | 16 | 125 | CL1251 | 3173 | |
| 3 | 14 | 125 | CL1251 | 3173 | |
| 4 | 12 | 125 | CL1251 | 3173 | |
| 5 | 18 | 150 | EXL-150 | 3321 | |
| 6 | 16 | 150 | EXL-150 | 3321 | |
| 7 | 14 | 150 | EXL-150 | 3321 | |
| 8 | 12 | 150 | EXL-150 | 3321 | |
| 9 | 10 | 150 | EXL-150 | 3321 | |
| 10 | 18 | 200 | SEW-1 | 3122 | |
| 11 | 16 | 200 | SEW-1 | 3122 | |
| 12 | 12 | 250 | | 3252 | |
| 13 | 16 | 250 | | 3252 | |
| 14 | 20 | 150 | EXL-150 | 3321 | |
| 15 | 8 | 150 | EXL-150 | 3321 | |
| 16 | 8 | 60 | | | |
| 17 | 10 | 60 | | | |



SW. A
MOTOR LATCH SW.
INTER. DE MOTOR DE CERROJO
INTER. MOTEUR VERROU



CAUTION: DISCONNECT POWER BEFORE SERVICING UNIT.
ATENCIÓN: CORTAR EL CORRIENTE ANTES DE REALIZAR EL MANTENIMIENTO DEL ELECTRODOMESTICO.
ATTENTION: COUPEZ L'ALIMENTATION AVANT D'EFFECTUER LA REPARATION.

318046116 REV. A