

## Microwave

FFCE1638LS



### Countertop

#### Product Dimensions

Height	12-7/8"
Width	21-3/4"
Depth	18-1/2"

#### More Easy-To-Use Features

##### Ready-Select® Controls

Easily select options with the touch of a button.

##### Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

##### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

##### Effortless™ Reheat

Reheat almost anything at the touch of a button.

##### Multiple-Stage Cooking Option

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

##### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

##### Control Lock Option

##### Electronic Clock/Timer

Helps you keep track of cook times.

##### Attractive Stainless Steel Exterior

##### Interior Light

Illuminates the contents of the microwave for increased visibility.

##### Large Glass Turntable

Even large items fit on our large glass turntable.

##### Available in:



Stainless  
(S)

### Signature Features

#### Sensor One-Touch Options

Microwave automatically adjusts power levels and cooking times to cook a variety of items, effortlessly.

#### Keep Warm Setting

Keep food warm until everything—and everyone—is ready.


#### Melt & Soften

Use the microwave to quickly melt or soften butter or cheeses for your recipes.

#### Easy-Set™ Start

Quickly start cooking—one to six minutes—with just one touch.

Features	
Control/ Timing System	Ready-Select®
Exterior Door Finish	Stainless Steel
Handle Design	Push Button
Microwave Features	
Microwave Capacity (Cu.Ft.)	1.6
Watts (IEC-705 Test Procedure)	1,100
Interior Light	Yes
Interior Color	White
Turntable Diameter	14-1/4"
Turntable On/Off	
Control Lock	Yes
Clock	Yes
Touch Pad Buttons	23
Power Levels	10
Accessory Metal Rack	
Microwave Control Options	
Easy-Set™ Start	Yes
Popcorn Button	Yes
Chicken Nugget Button	
Baked Potato Button	Yes
Sensor Reheat Button	Yes
Snack Button	
Beverage	Yes
Melt & Soften Options	4 / 4
Auto Reheat Options	
Snack Menu Options	
Auto Cook Options	
Auto Defrost Options	Yes
Keep Warm	Yes
Add-30-Seconds	Yes
Sensor Cooking Options	7
Vegetable Cook Sensor	Yes
Delay Start	
User Preferences	
Power Ratings	
Frequency (Mhz)	2,450
Watts @ 120 Volts	1,100
Amps @ 120 Volts	13
Specifications	
Oven Interior Height	10-5/16"
Oven Interior Width	17-1/4"
Oven Interior Depth	15-3/8"
Power Supply Connection Location	Rear
Voltage Rating	120V / 60Hz / 15A
Minimum Circuit Required (Amps)	15
Shipping Weight (Approx.)	47 Lbs.



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



Product Dimensions <sup>1</sup>	
A - Height	12-7/8"
B - Width	21-3/4"
C - Depth	18-1/2"

<sup>1</sup>A minimum clearance of 3 inches is required above microwave oven and between microwave oven and adjacent walls.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)