

Microwave

FFCM1134LS



Signature Features

Easy-Set™ Start

Quickly start cooking—one to six minutes—with just one touch.

Ready-Select® Controls

Easily select options with the touch of a button.

Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

Countertop

Product Dimensions

| | |
|--------|---------|
| Height | 12-3/4" |
| Width | 20-3/8" |
| Depth | 16-1/8" |

More Easy-To-Use Features

Effortless™ Reheat

Reheat almost anything at the touch of a button.

Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

Control Lock Option

Electronic Clock/Timer

Helps you keep track of cook times.

Attractive Stainless Steel Exterior

Interior Light

Illuminates the contents of the microwave for increased visibility.

Large Glass Turntable


Even large items fit on our large glass turntable.

Available in:



Stainless
(S)

| | |
|----------------------------------|-------------------|
| Features | |
| Control/ Timing System | Ready-Select® |
| Exterior Door Finish | Stainless Steel |
| Handle Design | Push Button |
| Microwave Features | |
| Microwave Capacity (Cu.Ft.) | 1.1 |
| Watts (IEC-705 Test Procedure) | 1,100 |
| Interior Light | Yes |
| Interior Color | White |
| Turntable Diameter | 12-3/8" |
| Turntable On/Off | |
| Control Lock | Yes |
| Clock | Yes |
| Touch Pad Buttons | 23 |
| Power Levels | 10 |
| Accessory Metal Rack | |
| Microwave Control Options | |
| Easy-Set™ Start | Yes |
| Popcorn Button | Yes |
| Chicken Nugget Button | |
| Baked Potato Button | Yes |
| Sensor Reheat Button | |
| Snack Button | |
| Beverage | Yes |
| Melt & Soften Options | |
| Auto Reheat Options | 4 |
| Snack Menu Options | |
| Auto Cook Options | 8 |
| Auto Defrost Options | Yes |
| Keep Warm | |
| Add-30-Seconds | Yes |
| Sensor Cooking Options | |
| Vegetable Cook Sensor | Yes |
| Delay Start | |
| User Preferences | |
| Power Ratings | |
| Frequency (Mhz) | 2,450 |
| Watts @ 120 Volts | 1,000 |
| Amps @ 120 Volts | 13 |
| Specifications | |
| Oven Interior Height | 9-1/4" |
| Oven Interior Width | 19-27/32" |
| Oven Interior Depth | 14-13/32" |
| Power Supply Connection Location | Rear |
| Voltage Rating | 120V / 60Hz / 15A |
| Minimum Circuit Required (Amps) | 14 |
| Shipping Weight (Approx.) | 30 Lbs. |



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at frigidaire.com.



| Product Dimensions¹ | |
|---------------------|---------|
| A - Height | 12-3/4" |
| B - Width | 20-3/8" |
| C - Depth | 16-1/8" |

¹A minimum clearance of 3 inches is required above microwave oven and between microwave oven and adjacent walls.

Accessories information available on the web at frigidaire.com