



- NOTE:
- |             |                       |           |          |
|-------------|-----------------------|-----------|----------|
| (CONDITION) | (OL) OVEN LED         | OG:ORANGE | BR:BROWN |
| DOOR:CLOSED | (FM) FAN MOTOR        | YW:YELLOW | WH:WHITE |
| COOK:OFF    | (TTM) TURNTABLE MOTOR | RD:RED    | BK:BLACK |
|             | (SM) STIRRER MOTOR    | BL:BLUE   | GY:GREY  |
|             | (CL) COOKTOP LED      | GN:GREEN  | PK:PINK  |
|             | (CM) CONVECTION MOTOR |           |          |
|             | (DM) DAMPER MOTOR     |           |          |