








Congratulations on your new GE Profile Combo !

What to expect when using your Combo


- 
No load transfer! Start a load before work, before you go to bed...or anytime.
 - When you choose **WASH** + **DRY**, your work is done. The Combo will wash and then gently dry your garments in just a couple hours. Finally, laundry is **One & Done**.
- 
Clothes may feel a little damp when the dry cycle ends, but they're actually dry.
 - Because your Combo dries clothes at low heat in a sealed drum, they may feel slightly damp or cool on first touch. Just take them out & shake them and they will feel dry in a few seconds.
- 
Wash + Dry a load in just a couple hours. Times may adjust before & during cycles.
 - Your Combo learns your load patterns, fabric types and habits. You may notice that the total cycle time will adjust during a cycle and from load to load based on load size, soil level and spin out after wash.
- 
Easy access dual-stage lint filter ensures high efficiency airflow.
 - Recirculating filtered, high speed air-flow allows the Combo to deliver great drying performance. You'll notice that less lint is generated through air tumbling versus standard dryers. Look for reminders to clean the filter.
- 
Simple to use with plenty of options! Explore all the features.
 - Don't mess with detergent & softener: **SmartDispense**.
 - Start the Combo from your phone: **Remote Start**.
 - Increase dryness level of your laundry: **More Dry**.
 - Reduce wrinkles at end of cycle: **Wrinkle Care**.
 - ¿No hablas inglés? : Cambiar **Language** en el **Menu**.
 - Toss in a dryer sheet: **Wash Complete**  tells you when.

How do I get started ?


A Remove shipping bolts, grommets & brace




B Level the Combo by adjusting the four legs and locking the clench nuts.




C Connect the hoses to the hot and cold water inlets.




D Connect the proper hot and cold hoses to the faucets and insert the drain tube into the standpipe.



E A simple 120V outlet is all the Combo needs. No 240V outlet needed! No external venting! It could go virtually anywhere.




F Connect the Combo using SmartHQ to your home wifi to enable updates & additional features.




Keep your Combo in top shape


Installation on a riser




Cleaning the filter




Self Clean cycle



Clearing the drain pump




Register your Combo



UltraFast Combo: The Only Machine You Need.

Basic Operation of your Combo



- 1** Power On the Combo & load it with sorted laundry items.
- 2** Check the filter on both sides.

To get the best drying efficiency, it's important to start with a clean filter.
- 3** Select a Wash + Dry cycle.

If desired, you can choose to run a Wash or Dry only.
- 4** Manually dose or use SmartDispense after filling with detergent and/or softener. Choose other Wash and Dry Options as desired.
- 5** When ready, tap the Start / Pause button and let the Combo do both the washing & drying, thanks to no load transfer.
- 6** If desired, check the SmartHQ app on your phone for notifications, to adjust options, add more dry time or to learn more about the Combo.

Advanced Features of your Combo

Timed Dry

Switch from Sensor to Timed Dry and adjust time in 15 min increments.

Downloaded Cycles

Use SmartHQ to add specialty cycles: Jeans; Air Fluff; Swimwear; or, PowerClean.

Wash Complete



My Settings



Change Language

The Combo can provide messages & cycle info in English, Spanish or French.

Dewrinkle

Help remove wrinkles from 1-8 dry garments using steam vapor and a gentle tumble.

EcoCool™ Cycle

For a cold water clean equal to a Normal warm wash, try the EcoCool low energy cycle.

Display & Sound Settings

Adjust screen brightness and signal volume right from the Menu.

More Water

Add an extra 3 gallons of water for wash and each rinse at the touch of a button.

Remote & Delay Start



Adaptive SmartDispense™



Eco Dry

From the Menu, turn Eco Dry mode ON to reduce the dryness level and use less total energy.

Cycle / Energy Monitoring

Use SmartHQ to get info on cycle history and energy usage.