




## 1.2 CUBIC FOOT MICROWAVE DRAWER

### MODELS:

JMDFS24HM01 (Floating Glass Black)

# DRAWER PARTS




# DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11257722	Use and Care Guide
2	W11201328	Tray, Oven
3	W11201390	Cover, Support
4	W11201870	Cover, Choke
5	W11315618	Assembly, Drawer
6	W11201873	Hook, Latch (Left)
7	W11201874	Spring, Latch
8	W11201872	Hook, Latch (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W11201775	Slide, Drawer
10	8205835	Screw
11	W11199897	Stopper, Door
12	W10278632	Screw
13	W10278889	Nut
14	W11315617	Support, Side
15	W11201804	Piston, Door Stop
16	W11201393	Support, Bottom
17	W11201777	Gear, Drawer

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10278647	Screw
19	W11331003	Panel, Door
		FOLLOWING PARTS NOT ILLUSTRATED
	W11199540	Cord, Power
	W11362536	Harness, Main
	W11315605	Fuse (20A)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8205835	Screw	3	W11199889	Bracket, Panel	6	W11330996	Control, Electronic
2	W11199895	Harness, Touch Control	4	8185369	Screw	7	W11199896	Wire, Ground
			5	W11199894	Cushion, Control	8	W11330999	Panel, Control


# OVEN CAVITY PARTS



# OVEN CAVITY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11199864	Bushing, Power Cord	12	W11199827	Bracket, Left	23	W11201857	Panel, Bottom Partition
2	W10278632	Screw	13	W11199547	Cut-Out, Thermal	24	W11201855	Glass, Lamp
3	W11199863	Bracket, Power Cord	14	W11362534	Motor, Stirrer	25	W11209962	Cover, Faceplate
4	W10278891	Screw	15	W11199858	Deflector	26	W11251704	Screw, Mounting (Wood)
5	W11201389	Cover, Rear	16	W11199828	Bracket, Right	27	W11251705	Screw, Deflector
6	W11199812	Case, Outer	17	W11201787	Bracket, Control Panel	28	W11199861	Cover, Latch
7	W11201800	Panel, Partition	18	W11201790	Cover, Lamp	29	W11362542	Shaft, Stirrer Motor
8	8185369	Screw	19	W10278184	Assembly, Lamp			
9	W11199539	Relay, Power	20	W11362539	Blade, Stirrer			
10	8205835	Screw	21	W11201789	Cover, Stirrer			
11	W11201748	Holder, Relay	22	W11362541	Clip, Cover			

# SWITCH PARTS






# SWITCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11199805	Microswitch
2	4174784	Screw
3	W11201860	Latch, Door (Left)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W11201858	Latch, Door (Right)
5	W11305909	Switch, Monitor (with Fuse)


# INTERIOR PARTS



# INTERIOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11362533	Motor, Fan	6	W11201793	Cushion, Inlet	13	W11201796	Cushion, Exhaust Duct
2	W11199545	Filter, Noise	7	W11209949	Magnetron	14	W11201802	Cushion, Air Flow
3	W11305909	Switch, Monitor (with Fuse)	8	W11201852	Duct, Sensor	15	W11199810	Assembly, Drawer Gear
4	W11201861	Cushion, Fan Motor Support	9	W10278023	Assembly, Sensor			
5	W11331002	Duct, Magnetron	10	W11201803	Cushion, Duct			
			11	W10278632	Screw			
			12	W11201854	Duct, Exhaust			

# BASE PLATE PARTS



# BASE PLATE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11199538	Supply, Power	5	W11201396	Bracket, Capacitor	8	W11202128	Cover, Waveguide
2	8185369	Screw	6	W11201794	Cushion, Transformer	9	W10278632	Screw
3	W11201745	Holder, Control	7	W11199548	Transformer, High Voltage	10	W11201391	Plate, Base
4	W11362530	Capacitor, High Voltage				11	8205835	Screw