

Use and Care Manual Expressions 'Big Pot' Canning Grate

Model AG146


About The Expressions "Big Pot" Canning Grate

The Canning grate is to be used only with Jenn-Air Expressions Gas cooktops. This optional accessory makes it possible to use large over-sized canners or stockpots on the cooktop. Normally canners should not be allowed to extend over the edge of the grate. Heat build-up under the canner could damage surrounding areas. The elevated design of the Canning grate eliminates such problems.

Installing and Using The "Big Pot/Canning" Grate

Note: The large front burner has been designed to supply the highest BTU rate. When canning, use this burner <u>only</u>.

- Before installing the canning grate, be certain ALL control knobs are in the "OFF" position and the cooktop grate is cool.
- 2. Remove the burner grate from the large front burner of the cooktop.
- Place the canning grate in its place. The large flat portion should extend forward over the countertop. Add the surface burner grate on top of the canning grate.



- 4. Use the surface control knob for the large front burner.
- 5. The grate can be removed for storage once it has cooled.

Procedures When Using The Canning Grate

- CAUTION: The canner or cookpot should be centered and balanced on the canning grate.
- Bring water to boil at HI setting; after boiling has begun, reduce heat to lowest setting that will maintain boiling.
- Cover canner or cookpot when bringing water to boil to save energy and to speed cooking.
- Use canning recipes from a reputable source such as the manufacturer of your canner, manufacturers of canning jars and the USDA Extension Service.
- Canning is a process that creates large amounts of steam. Be careful and follow equipment instructions to avoid burns from steam or hot canners.
- If your area has low gas pressure, canning may take longer than indicated by the directions.
- Refer to the Use and Care Manual for your Jenn-Air appliance for additional information.

