


NZ30R5330R

30" Electric Cooktop

SAMSUNG



Signature Features

Flexible Cooktop

- Whether you're boiling water, melting chocolate or simmering sauce, there's an element for your needs.

Front Controls

- Front Controls are easy to reach.

Indicator Light

- Hot Surface Indicator light lets you know the surface is hot.

Available Color



Black



Front Controls



Indicator Light

Features

- Flexible Cooktop
 - Right Front: 5"/8", 2 kW
 - Left Front: 7", 1.5 kW
 - Left Rear: 7", 1.5 kW (Simmer)
 - Center: 9", 2.5 kW
- 7.5 kW Total Power
- ADA Compliant

Convenience

- Hot Surface Indicator Light
- Easy-To-Clean Glass, Ceramic Cooktop
- Dishwasher-Safe Knobs



ADA Compliant

30" Electric Cooktop

Installation Requirements

Diagram illustrating the required clearances for a sink installation:

- Rear Wall:** Indicated by an upward arrow.
- Left Side Clearance:** $1\frac{1}{8}"$ Min.
- Right Side Clearance:** $1"$ Min.
- Front Clearance:** $1\frac{1}{2}"$ Min.
- Bottom Clearance:** $1"$ Min.
- Overall Width:** $19\frac{9}{16}" - 19\frac{5}{8}"$
- Overall Depth:** $28\frac{1}{2}" - 28\frac{11}{16}"$

Minimum distance to combustible side wall above countertop (both sides)

* See built-in oven manual for complete installation instructions. See label on top of approved built-in oven models.

** Refer to installation manual of oven.

A perspective diagram of a rectangular plate. The top surface is labeled with a width of 30" and a depth of 21 1/4". The bottom surface is labeled with a width of 28 3/8" and a depth of 19 7/16". The diagram shows the plate's thickness and the relationship between the top and bottom dimensions.

©2019 Samsung Electronics America, Inc. 85 Challenger Road, Ridgefield Park, NJ 07660. Tel: 800-SAMSUNG, samsung.com. Samsung is a registered trademark of Samsung Electronics Co. Ltd.

