




Design

- Integrated blower can be purchased separately and installed within the hood
- Always refer to installation manual for detailed instructions



measurements in inches and mm