

PJEZ controller setting

1. Press and hold the SET button for at least 3 seconds (to mute the buzzer during an alarm) to display the “PS” (passcode) code
2. Press the SET button to enter the passcode;
3. Use the UP or DOWN buttons to scroll through the numbers until “22” is displayed (the passcode for accessing parameters);
4. Press the SET button to confirm the password;
5. Use the UP and DOWN buttons to scroll through the parameters until you find the “rd” code:
6. Press the SET button to display the value associated with the parameter;
7. Use the UP or DOWN buttons to increase or decrease the parameter value, changing the original “7” to “3”;
8. Press the SET key to temporarily save the new parameter value and display the parameter again;
9. Press and hold the SET key for at least 3 seconds to permanently save the parameter and exit the parameter setting mode.

Friendly Reminder:

If no keys are pressed within 60 seconds, all changes to the parameters temporarily stored in RAM will be canceled, and the parameters will revert to their previous settings.