

DOOR REVERSAL INSTRUCTIONS

If the appliance is placed on its back or side during this process it must be allowed to stand upright for 6 hours before plugging in to avoid damage to internal components.

1. Remove the screw hole cover from the top left side of the cabinet. Remove the upper hinge cover and the upper hinge from the top right side of the cabinet. Remove the freezer door from the cabinet.
2. Remove the hinge pin from the upper hinge. Flip the upper hinge over. Reinstall the hinge pin on the opposite side of the hinge.
3. Remove the center hinge from the cabinet. Remove the refrigerator door from the cabinet.
4. Move the hinge hole sleeve from the top right side of the refrigerator door to the top left side of the refrigerator door. Move the hinge hole cover from the top left side of the refrigerator door to the top right side of the refrigerator door.
5. Move the screw hole covers from the center left side of the cabinet to the center right side of the cabinet.
6. Remove both adjustable feet from the bottom of the cabinet.
7. Remove the lower hinge from the bottom right side of the cabinet.
8. Move the screw hole covers from the bottom left side of the cabinet to the bottom right side of the cabinet.
9. Remove the hinge pin from the lower hinge. Flip the lower hinge over and install the hinge pin on the other side. Install the lower hinge on the lower left side of the cabinet.
10. Install both of the adjustable feet on the bottom of the cabinet.
11. Install the refrigerator door on the cabinet. Flip the center hinge and install it on the center left side of the cabinet.
12. Install the freezer door on the cabinet. Install the upper hinge and the upper hinge cover on the top left side of the cabinet. Install the screw hole cover on the top right side of the cabinet.

