




30" ELECTRIC BUILT-IN COOKTOP

MODELS:

WCE97US0HB00 (Black)

WCE97US0HS00 (Stainless)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Box, Burner (Not Serviced)	16	W11177346	Top, Foam (Heat Shield)
	W11206696	Instructions, Installation	9	W11115967	Assembly, UI	17		Cover, Win Port (Not Serviced)
	W11245478	Instructions, Undercounter Installation	10	W11179387	Antenna	18	W11175302	Rail, Vertical
	W11214273	Guide, Use & Care	11	W10275048	Element (3000/1400W)	19	W11175346	Rail, Horizontal
	W11227340	Diagram, Wiring			(Left Front & Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W11228285	Guide, Internet Connectivity		8273993	Element (1800W) (Left Rear)	W11111811		Harness, Main
2		Cooktop		8273994	Element (1200W) (Center Front)	3400015		Screw, Grounding
	W11120982	Black		W10799048	Element, Warm Zone (Center Rear)	7101P520-60		Screw
	W11120983	Stainless	12	W11179787	Assembly, LOKI WiFi	7103P027-60		Nut
3		Trim, Front Stainless (Not Serviced)				3192439		Seal, Limiter
4	W11102056	Shield, Heat	13	4455917	Bracket, Cooktop Mounting	8286642		Tape, Foam
5	W10225448	Spring, Element	14	3400093	Screw	W11160362		Insulation, Cooktop
6	W11115981	Manager, Expansion Appliance	15	7101P426-60	Screw			
7	W11115991	Manager, Copernicus Appliance						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	WA906B	Scraper, Cooktop
W10355051		Cleaner, Cooktop
	31464	Cleaner, Cooktop
	31463	Protectant, Cooktop
	242905	Kit, Canning Unit
	31605	Kit, Cooktop Care