




**30" BUILT-IN ELECTRIC COMBINATION MICROWAVE WALL OVEN  
(Fingerprint Resistant)**

**MODELS:**

WOCA7EC0HN01 (Sunset Bronze)

WOCA7EC0HZ01 (Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	7101P426-60	Screw	14	W10588732	Chassis, Cover Top Back 30"
	W11220324	Guide, Use & Care (Oven)	9	W10681157	Cover, Combo Blower			
	W11108505	Guide, Use & Care (Microwave Oven)	10	W10655463	Bracket, Blower (Left)			FOLLOWING PARTS NOT ILLUSTRATED
	W11129957	Instructions, Installation		W10655462	Bracket, Blower (Right)		W11225386	Harness, Main
	W11097305	Guide, Internet Connectivity	11	W10728475	Gasket, Rubber		W11225392	Harness, Signal
	W11108420	Sheet, Tech	12	W10618126	Chassis, Back Divider		W10874059	Harness, Fan & Turntable
	W11108426	Diagram, Wiring	13	W10318158	Chassis, Cover Top Front 30"		W10874060	Harness, Inverter
2	W11234541	Antenna					W10720308	Harness, Interlock
3	W11253186	Appliance Manager, Copernicus (With Power Supply)					W11233537	Jumper Harness, Communication
4	W10655467	Chassis, Combo Side					W11233569	Harness, Ground Console Combo
5	W11200129	Blower					W11233529	Harness, Communication
6		Assembly, Control Panel (Includes Overlay)					W11132989	Harness, Door Latch
	W11105054	Sunset Bronze					W10889134	Harness, Cable Tree Assembly
	W11105052	Stainless					4450800	Screw, Grounding
7		Skin, Control Panel					4448664	Clamp, Conduit
	W10892169	Sunset Bronze					313438	Clip, Harness
	W10893983	Stainless					4454842	Tie, Cable


# OVEN PARTS



# OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8285593	Cover, Connector	17	W10472384	Bulb, Light	32	W11045086	Receiver, Slow Close Hinge
2	W11085298	Tube, Vent	18	4449751	Thermostat (TOD)	33	W11034940	Shield, Slow Close Hinge
3	W11044775	Receiver, Hinge	19	W10834867	Base, Chassis	34	W10681156	Deflector, Chassis
4	W10618102	Spacer, Base	20		Assembly, Bottom Vent	35		Trim, Side
5	W10618131	Latch, Motorized		W10921397	Sunset Bronze		W10344483	Black (Left)
6	W10904158	Top, Chassis		W10869571	Stainless		W10344482	Black (Right)
7	W11198684	Assembly, Oven Light	21	W10283008	Chassis, Bottom Duct	36	W10834286	Spacer, Center
8	W10283021	Support, Base (Right)	22	W10283020	Support, Base (Left)	37	W10254050	Screw
9	W10904163	Deflector, Blower	23	W10213759	Support, Air Channel			FOLLOWING PARTS NOT ILLUSTRATED
10	W10495154	Vent, Center 30"	24	W10351308	Spacer, Chassis Bottom Duct		W10520715	Insulation, Wrap
11	W10739089	Gasket	25	W10351278	Bumper & Screw		W10282944	Insulation, Cavity
12	W10616810	Cover, Vent Exhaust	26	W10472386	Lens, Light		W10464568	Insulation, Control Knob
13	W10663556	Side, Chassis (Left)	27	7101P426-60	Screw			
	W10318190	Side, Chassis (Right)	28	W10616809	Base, Vent Exhaust			
14	W10904160	Back, Chassis	29	7101P427-60	Screw			
15		Liner, Oven (Not Serviceable)	30	W10834501	Spacers, Front			
16	W10622170	Probe, Sensor	31	W11037653	Cover, Combo Chassis Back Duct (With Hole)			


# OVEN DOOR PARTS



# OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10347596	Assembly, Window Pack	7		Assembly, Door	12	7101P426-60	Screw
2	W10284285	Spring, Door Glass Fixation		W10866271	Sunset Bronze	13	7101P653-60	Screw
3	3196183	Screw		W11028416	Stainless	14	W10653954	Clip, Spring Metal
4	W10884775	Nameplate	8		Assembly, Handle	15	W10319024	Washer, Door
5	W10709147	Assembly, Liner		W11176370	Stainless	16	7101P635-60	Screw (Black)
6	W11045551	Hinge, Slow Close Door	9	W10678524	Glass, Inner			
			10	W10284297	Bracket, Glass			
			11	W10480830	Screw			

# INTERNAL OVEN PARTS






# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10260252	Element, Broil	7	W10546517	Element, Bake	14	W10696226	Jack, Meat Probe
2	W11122597	Rack, Oven	8	W10722667	Fan, Convection	15	W11033111	Nut, Locking
3	W10318198	Tray, Hidden Bake	9	W10631503	Blade, Fan	16	W10906658	Screw
4	7101P434-60	Screw	10	W10631504	Nut, Acorn (LH)	17	9755542	Probe, Temperature
5	7101P426-60	Screw	11	W10720084	Screw			
6	W10282957	Crossbar, Hidden Bake Tray	12	W10260248	Ring, Element			
			13	W10914672	Baffle, Convection			


# CABINET AND STIRRER PARTS



# CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10840522	Control, Electronic	17	423107022541	Reflector	33	461967753742	Adapter, Turntable Motor
2	461967017491	Trim, Side (Left)	18	423107720491	Lens, Lamp	34	461967008461	Support, Bottom
3	461967017481	Trim, Side (Right)	19	461967010591	Clip, Spring	35	461967510191	Bushing
4	461968973241	Vent, Top Microwave	20	461967848971	Motor, Turntable	36	W10769147	Sealing, Lamp
5	W10692851	Filter, Noise	21	461967825321	Screw	37	461967754821	Duct, Magnetron
6	461967848621	Transformer, Light (20V)	22	46196897960	Hinge, Door	38	423107570871	Spring, Release Rod
7	241908600053	Fuse	23	461968969271	Assembly, Cooling Fan	39	461967842541	Thermoactuator
8	4375231	Block, Fuse	24	W10468206	Inverter	40	461967848251	Motor, Convection Fan
9	461967846741	Thermostat, Magnetron	25	461967825971	Screw	41	461967848711	Heater, Convection Element
10	461967847321	Magnetron	26	W10120235	Rod, Release	42	461967001792	Fan, Convection
11	W10465869	Spring, Lamp	27	251968600013	Pin, Damper	43	423107845441	Sensor, Convection
12	W10490593	Holder, Lamp	28	461967570351	Spring, Torsion			
13	W10795595	Lamp, Halogen	29	461967750494	Support			
14	241960100002	Sensor, Temperature	30	461967750483	Arm, Sliding			
15	W10330566	Switch	31	W10460457	Sensor, Humidity			
16	8205683	Holder, Switch	32	W10358241	Assembly, Interlock Switch			


# INTERNAL MICROWAVE PARTS



# INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461967721091	Turntable	6	252262898008	Support, Spring Lock Grill	10	W10748279	Rack, Low Convection
2	W10367316	Ring, Turntable				11	W10815868	Steamer
3	W10545578	Drive, Turntable	7	W10387651	Element, Grill	12	W10750839	Plate, Baking
4	461967451001	Plate, Cover	8	461968977491	Plate, Crisp			
5	461967753871	Support, Element	9	461968929542	Handle, Pan			


# TOP VENTING PARTS



# TOP VENTING PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	7101P060-60	Screw	7	W10519707	Cover, Back Duct	10	W10356437	Cover, Slot Module
2	4454949	Holder, Fuse	8	W10655466	Chassis, Combo Side (Left)	11	W10710302	Rail, Side (Left)
3	7101P426-60	Screw		W11037649	Chassis, Combo Side (Right)	12	W10710309	Rail, Side (Right)
4	8285593	Cover, Connector	9	W10283022	Support, Crossbar			
5	W10283024	Side, Bracket						
6	W10017410	Fuse, Time Delay						

# MICROWAVE DOOR PARTS





# MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8304588BL	Cap, Screw	5		Assembly, Outer Door	6		Assembly, Handle
2	W10359769	Foam, Door Handle		W10866279	Sunset Bronze		W11176370	Stainless
3	W10687342	Assembly, Inner Door		W11028415	Stainless	7	W10319024	Washer, Door
4	W10480830	Screw						

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
	W10123240	Rack, Broiler Pan & Roasting
	W10355016	Cleaner, Stainless Steel
	4396923	Grid, Broiler Pan and
	8205262RB	Steamer, Microwave
	W10355049	Wipes, Stainless Steel Cleaning
	W10745649	Rack, Sliding