



FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:


WRF560SEHW00 (White)

WRF560SEHB00 (Black)

WRF560SEHV00 (Black Stainless)

WRF560SEHZ00 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	12	549193	Clamp, Power Cord	25		Cover, Hinge
	W10641018	Tech Sheet	13	489497	Screw		W10465765	Left Hand (White)
	W11112396	Energy Guide	14		Hinge, Center		W10465764	Right Hand (White)
	W10360467	Use and Care Guide		W10770878	Left Hand		W10465771	Left Hand (Black)
	2225623	Icemaker Service Sheet		W10770877	Right Hand		W10465770	Right Hand (Black)
2		Hinge, Top	15	W10450363	Shim, Center Hinge		W10465768	Left Hand (Grey)
	W10546298	Left Hand	16	2262176	Screw		W10465767	Right Hand (Grey)
	W10546299	Right Hand	17		Rail, Center (Not Serviced)	26		Cabinet (Not a Serviceable Part)
3		Roller, Front	18		Fitting, Water Tube (Not Serviced)	27	2174706	Clip, Roller
	W10359256	Left Hand	19	W10636716	Cover, Unit	28	W10463317	Tube, Cabinet Water
	W10359255	Right Hand	20		Filler, Corner	29	W10331226	Drum, Toe Grille
4	W10569758	Filter, Water		W11189128	White	30	W10782423	Locking Ring (1/4)
5	W10346257	Housing, Water Filter		W11189127	Black		W10782424	Locking Ring (5/16)
6	W10306392	Cover, Water Filter		W11189126	Grey	31	W10837812	Tube, Water
7	489497	Screw	21		Grille	32	W10279866	Assembly, Dual Valve
8		Cover, Toe Grille		W10300127	White	33	W10498992	Valve, Inlet
	W10339257	White		W10353933	Black	34	W10237915	Bracket, Water Valve
	W10353930	Black	22	1106508	Gasket, Seal			
	W10353932	Grey	23	W10601149	Fitting, Water Tube			
9	489442	Screw	24	W10667756	Tube, Filter Outlet			
10	W10141622	Brake, Roller						
11	W10740689	Tube, Filter Inlet						

LINER PARTS




LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	2197380	Grommet
3	W10468762	Gasket, Evaporator Cover
4	W10536362	Assembly, LED Light
5	W10469878	Housing, Light
6	W10798439	Container, Water Reservoir
7	12466105	Switch, Light
8	W10487766	Assembly, Freezer Wire
9	W10459385	Cover, Control Housing
10	W10464673	Motor, Fan
11	2200509	Blade, Fan
12	W10453580	Housing, Control
13	W10336009	Cup, Screw
14	W10448448	Assembly, Multiflow
15	488208	Screw
16	W10300900	Cover, Evaporator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10317182	Tower, Freezer
18	W10384183	Thermistor
19	1118894	Switch, Rocker Arm
20	W10413160	Cover, Water Reservoir
21	W10568672	Reservoir, Water
22	W10271541	Connector, Union
23	W10425252	Cover, Thermistor
24	W10330850	Grille, Air Filter Bottom
25	W10315189	Filter, Air
26	W10356895	Tower, Multiflow Air
27	W10314195	Shield, Heat
28	W10321162	Bracket, Fan Motor
29	489478	Screw
30	2254454	Bracket, Evaporator Fan Rear
31	W10313917	Housing, Freezer Lighting
32	W10313918	Lens, Light
33	W10440814	Socket, Light

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
34	W10809513	Bulb, Light
35	W10745484	Damper, Electronic Control
36	W10474774	Cover, Damper Housing
37	W10314204	Housing, Damper
38	W10632400	Assembly, Icemaker
39	W10309400	Assembly, Ice Maker Wire
40	W10474785	Arm, Shut Off
41	W10289690	Cover, Icemaker
42	W10378263	Pan, Ice


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left (Includes #8)	5	W10884775	Nameplate	12	W10326335	Bin, Shallow
	W10557489	White	6	W10470155	Closure, Door	13		Assembly, Flipper Mullion
	W10557491	Black	7	W10308869	Bin, Medium		W10624451	White
	W11222542	Black Stainless	8		Gasket, Door		W10624448	Black
	W11222545	Stainless		W10353189	Beige		W10624450	Grey
2		Door, Right (Includes #8)		W10413465	Black	14	12990302	Screw
	W10353181	White		W10413468	Grey	15	W10170540	Screw
	W10413518	Black	9		Assembly, Handle	16	W10397055	Bracket, Door Stop
	W10865738	Black Stainless		W11101973	White	17		Thimble
	W10858417	Stainless		W11101974	Black		W10492018	White
3	489276	Screw		W11101972	Black Stainless		W10334042	Black
4	W10366270	Thimble		W11101971	Stainless		W10492022	Grey
			10	W10317224	Compartment, Utility	18	2189202	Bracket, Door Stop
			11	W10462299	Caddy, Condiment			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Items 2 & 3)	2		Thimble	4		Assembly, Handle
	W10353182	White		W10492018	White		W11125499	White
	W10413530	Black		W10334042	Black		W11125500	Black
	W10865766	Black Stainless		W10492022	Grey		W11125496	Black Stainless
	W10858419	Stainless	3		Gasket, Door		W11125495	Stainless
				W10465758	Beige	5	W10170540	Screw
				W10465761	Black			
				W10465762	Grey			



UNIT PARTS



UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300116	Baseplate	20	W10236396	Strap, Compressor	40	W10519112	Valve, Drain
2	2319835	Grommet, Condenser	21	W10174384	Strap, Bale	41	2215468	Insulation, Sound
3	W10342567	Condenser	22	2315541	Bracket, Condenser Fan			Following Parts Not Illustrated
4	W10436849	Heater, Defrost	23	W10530280	Motor, Condenser	978025		Valve, Access (1/4")
5	W10321158	Assembly, Evaporator	24	W10633276	Assembly, Unit Wire	978026		Valve, Access (5/16")
6	8533961	Screw	25	W10817071	Blade, Fan	978027		Valve, Access (3/8")
7	W10314195	Shield, Heat	26	VS20001	Tube, Process	978029		Valve, Access (5/8")
8	W10271541	Connector, Union	27	488500	Screw	978030		Valve, Access (3/4")
9	W10314199	Tube, Drain	28	W10445423	Compressor	876764		Valve, Access (3/16")
10	W10248621	Clip, Condenser	29	W10669573	Drier			REFRIGERANT CHARGE
11	W10424230	Assembly, Low Voltage Wire	30	W10349514	Cover, Condenser Bottom			4.25 oz (R-134A)
12	W10892333	Control, Electronic	31	W10815861	Clip, Bottom Cover			
13	2323186	Box, Control	32	W10590083	Capacitor			
14	10835903SP	Grommet, Compressor	33	W10802027	Tray, Drain			
15	W10448874	Device, Start	34	W10510988	Tube, Suction			
16	W10313215	Cover, Electronic Control	35	2263990	Tie, Wire			
17	W10475495	Roller	36	2258429	Heat Probe			
18	2179826	Axle, Rivet	37	489478	Screw			
19	8533859	Screw	38	W10314197	Bracket, Evaporator			
			39	2219077	Clip, Harness			


SHELF PARTS



SHELF PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10486290	Assembly, Full Shelf (30")	10	W10356844	Control, Humidity	18	W10555437	Bin, Upper Freezer
2	W10502933	Assembly, 2/3 Flip Shelf	11	W10513681	Glass, Pantry Cover	19	W10628712	Axle, Roller
3	W10468557	Rail, Track (Center)	12	W10397907	Assembly, Pantry Deli Pan	20	W10317289	Basket, Lower Freezer
4	W10313893	Shelf, 2/3 Flip	13	W10397908	Rail, Pantry (Left Hand)	21	W10802342	Shaft, Rack
5	W10468556	Rail, Track (Right Hand)	14	W10414530	Rail, Pantry (Right Hand)	22	W10277361	Collar, Gear
6	W10468555	Rail, Track (Left Hand)	15	W10628713	Roller, Pan	23		Adaptor, Freezer
7	W10370327	Pan, Crisper (16")	16	W10346771	Filter, Produce Preserver		W10397636	Left Hand
8	W10317184	Pan, Crisper (8")	17	W10507470	Assembly, Pantry Cover Support		W10397635	Right Hand
9	W10408748	Holder, Produce Filter						

DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W11027238	Assembly, User Interface	9	W10356017	Ring, Trim
2		Drip Tray	6		Cover, Separator	10	2305235	Assembly, Spigot
	W10300448	White		W10356029	Chromium Frost	11	W10445080	Tube, Water Dispenser
	W10356018	Black	7		Assembly, Single Pad			
	W10356019	Grey		W10433547	White			
3	W10300437	Separator		W10433546	Black			
4		Fascia, Sparsh		W10433548	Grey			
	W10435575	Silver Mirror	8	W10735841	Assembly, Dispenser Wire			
	W10435576	Black						

OPTIONAL PARTS

FOLLOWING PARTS NOT ILLUSTRATED

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	511873	White Porcelain (2 oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	606755	Bag
	503695	Cork, Sealer

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque