


30" GAS COOKTOP

MODELS:

WCG55US0HS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

Illus. No.	Part No.	<u>Description</u>	Illus. No.	Part No.	<u>Description</u>	Illus. No.	Part No.	<u>Description</u>
1	W11116971	Literature Parts Instructions,	8	8286813	Head, Burner (Left Front)	14	W10758282	Screw FOLLOWING PARTS
		Installation		8286815	Head, Burner			NOT ILLUSTRATED
	W10672375	Instructions, Undercounter Install			(Left Rear & Right Rear)		W10868534	Harness (Switch), Main
	W11120470	Guide, Use & Care		8286814	Head, Burner (Right Front)			Cord, Power
	W11168236	Instructions, LP Conversion	9	W10625915	Grommet		W10132200 313438	Relief, Strain Clip, Harness
2		Cooktop	10	8286921	Black Screw, Burner Rail (M4)		W11173306	Kit, LP Conversion
	W11131855	Stainless	10	0200921			3801F935-51	Bracket, Tie Down
3		Kit, Burner Cap	11	W10652711	Orifice		7101P062-60	Screw
	W10597129	Black			(Left Front)			(For Tie Down Bracket)
4	14/44047007	Kit, Grate		W10609592	Orifice			
5	W11047087 8286863	Black Spring, Electrode			(Left Rear)			
	0200003	,		W10652710	Orifice			
6	W11084623	Knobs, Cooktop		W40400444	(Right Front) Orifice			
7	W11084623 W10594399	Stainless Holder, Orifice (5K)		W10409144	(Right Rear)			
,	VV 10394399	, , ,	12	W10541842	,			
	W40600E04	(Left Front)			•			
	W10609591	Holder, Orifice (15K)			(Left Front & Right Front)			
	W10594402	(Left Rear) Holder,Orifice (9.1K)		W10541843	Wiring, Electrode			
	W10597159	(Right Front) Holder, Orifice (12K)			(Left Rear & Right Rear)			
	** 10007 109	(Right Rear)	13	W10826075	Rear, Hinge-Grate (Stainless Model Only)			

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

Illus. No.	Part No.	Description	Illus. No.	Part No.	Description	Illus. No.	Part No.	Description
NO.	rait No.	Description	140.	rait No.	Description	<u>140.</u>	rait No.	Description
1	8287057	Screw, Valve Bracket	7	W10449143	Regulator, Pressure	14	W10566289	Tubing, Gas Burner
2	W10594394	Assembly, Manifold	8	W10594429	Bracket, Orifice Holder			(Right Rear)
3	W10597157	Valve, Single (Left Front)	9 10	W10475148	Module, Spark Box, Burner (Not Serviced)	15	7101P426-60	Screw FOLLOWING PARTS NOT ILLUSTRATED
	W10594391	Valve, Single (Left Rear & Right Rear)	11	W10566287	Tubing, Gas Burner (Left Front)		W10685483	Griddle Knobs
	W10594393	Valve, Single	12	W10566288	Tubing, Gas Burner		W10698166	Stainless Kit, Grates
4	8287055	(Right Front) Bracket, Single Valve	13	W10566290	(Left Rear) Tubing, Gas Burner		W10594440	Gray
5	W10140571	Seal, Switch Shaft			(Right Front)			
6	W10614950	Panel Front			, ,			

5