



30" 5 BURNER GAS COOKTOP


MODELS:

WCG77US0HS00 (Stainless)

COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286814	Head, Burner (Left Front, Left Rear, & Right Front)	13	W10758282	Screw FOLLOWING PARTS NOT ILLUSTRATED
	W11116971	Instructions, Installation						
	W10672375	Instructions, Undercounter Install		8286813	Head, Burner (Right Rear)		W10868535	Harness, Main
	W11120470	Guide, Use & Care		8286815	Head, Burner (Center)		W10392003	Cord, Power
	W11168236	Instructions, LP Conversion	9		Grommet		W10132200	Relief, Strain
2		Cooktop		W10625915	Black		313438	Clip, Harness
	W11131859	Stainless	10	W10826075	Rear, Hinge-Grate (Stainless Model Only)		W11173306	Kit, LP Conversion
3		Kit, Burner Cap					3801F935-51	Bracket, Tie Down
	W11169224	Black	11	W10652710	Orifice (Left Front & Left Rear)		7101P062-60	Screw (Used for Tie Down Bracket)
4		Kit, Grate		W10151347	Orifice (Right Front)			
	W11047085	Black		W10652711	Orifice (Right Rear)			
5	8286863	Spring, Electrode		W10609592	Orifice (Center)			
6		Knobs, Cooktop		W10609592	Orifice (Center)			
	W11084623	Stainless	12	W10541842	Wiring, Electrode (Left Front, Left Rear, & Right Front)			
7	W10597166	Holder, Orifice (9.1K) (Left Front & Left Rear)		W10541843	Wiring, Electrode (Right Rear)			
	W10613381	Holder, Orifice (10K) (Right Front)		W10611443	Wiring, Electrode (Center)			
	W10594399	Holder, Orifice (5K) (Right Rear)						
	W10609591	Holder, Orifice (15K) (Center)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8286921	Screw, Burner Rail (M4)	5	W10566302	Tubing, Gas Burner (Center, Main)	13	W10566295	Tubing, Gas Burner (Left Rear)
2	W11170045	Assembly, Pipe Manifold	6	W10614950	Panel, Front	14	W10566290	Tubing, Gas Burner (Right Front)
3	W10594392	Valve, Single (Left Front)	7	W10449143	Regulator, Pressure	15	W10566289	Tubing, Gas Burner (Right Rear)
	W10594391	Valve, Single (Left Rear & Center)	8	W10594429	Bracket, Orifice Holder			FOLLOWING ACCESSORIES NOT INCLUDED
	W10594393	Valve, Single (Right Front)	9	W10475149	Module, Spark (5+0)			
	W10597156	Valve, Single (Right Rear)	10	W10728415	Box, Burner			
4	8287055	Bracket, Single Valve	11	W10140571	Seal, Switch Shaft		W10685483	Griddle
			12	W10566287	Tubing, Gas Burner (Left Front)			