




30" 5 BURNER GAS COOKTOP

MODELS:

WCG97US0HS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286814	Head, Burner (Left Front, Left Rear, & Right Front)	15	W10685483	Griddle FOLLOWING PARTS NOT ILLUSTRATED
	W11116971	Instructions, Installation						
	W10672375	Instructions, Undercounter Install		8286813	Head, Burner (Right Rear)		W10868533	Harness, Main
	W11120470	Guide, Use & Care		W10611434	Head, Burner (Center)		W10392003	Cord, Power
	W11168236	Instructions, LP Conversion	9		Grommet		W10132200	Relief, Strain
2		Cooktop		W10625915	Black		313438	Clip, Harness
	W11131860	Stainless	10	W10826075	Rear, Hinge-Grate (Stainless Model Only)		W11173306	Kit, LP Conversion
3		Kit, Burner Cap					3801F935-51	Bracket, Tie Down
	W10613386	Black	11	W10151347	Orifice (Left Front, Left Rear, Right Front)		7101P062-60	Screw (Used for Tie Down Bracket)
4		Kit, Grate					9760045	Seal, Foam
	W11047085	Black		W10652711	Orifice (Right Rear)		8270P188-60	Tape, Foam
5	8286863	Spring, Electrode		W10672111	Orifice (1.65MM) (Center, Main)			
6		Knobs, Cooktop		W10151362	Orifice (Center, Simmer)			
	W11084624	Stainless	12	W10541842	Wiring, Electrode (Left Front, Right Front)			
7	W10613381	Holder, Orifice (10K) (Left Front, Left Rear, Right Front)		W10541843	Wiring, Electrode (Left Rear, Right Rear)			
	W10594399	Holder, Orifice (5K) (Right Rear)	13	W10758282	Screw			
	W11168367	Holder, Orifice Stack (17K) (Center)	14	W10763330	Electrode, Stack (Center)			

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8286921	Screw, Burner Rail (M4)	5	8287056	Bracket, Dual Valve	14	W10566299	Tubing, Gas Burner (Right Front)
2	W10594395	Assembly, Pipe Manifold	6	W10614950	Panel, Front	15	W10566298	Tubing, Gas Burner (Right Rear)
3	W10594392	Valve, Single (Left Front)	7	W10449143	Regulator, Pressure	16	W10566296	Tubing, Gas Burner (Center, Main)
	W10594391	Valve, Single (Left Rear)	8	W10594429	Bracket, Orifice Holder	17	W10443110	Screw
	W10594393	Valve, Single (Right Front)	9	W10475149	Module, Spark (5+0)	18	W10594430	Bracket, Orifice Holder (Center)
	W10597156	Valve, Single (Right Rear)	10	W10728415	Box, Burner	19	W10566297	Tubing, Gas Burner (Center, Simmer)
	W10594389	Valve, Dual (Center)	11	W10140571	Seal, Switch Shaft			
4	8287055	Bracket, Single Valve	12	W10566294	Tubing, Gas Burner (Left Front)			
			13	W10566295	Tubing, Gas Burner (Left Rear)			