



GAS DRYER


MODELS:

WGD4850HW0 (White)

TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10416486	Panel, Rear Console	15	3389682	Spacer, Toe Panel
	W11185731	Use and Care Guide	7	90767	Screw	16	W10865758	Harness, Wiring
	W11185733	Use and Care Guide/SP	8	688983	Screw	17	3348629	Screw
	W10848818	Installation Instructions	9		Top	18	694419	Buzzer, Mini
	W10876312	Wiring Diagram		8559800	White	19	W10420747	Switch, Rotary
2	693995	Screw	10		Knob, Push To Start	20	W10446920	Switch, Push to Start
3		Assembly, Timer Knob		W11160348	White			
	W11158829	White	11	W10436302	Timer Assembly (60 Hz.)			
4	8536939	Clip, Spring	12		Assembly, Console			
5		Lint Screen		W11178662	White			
	W10717210	White	13	8312709	Clip, Console			
			14	W10298336	Nut, "U"			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8066217	Hinge, Top	16	W10561321	Foot, Dryer	30	3400500	Bolt
2	343641	Screw		W10570316	Foot - Package of 4 (Not Included)	31	348780	Base, Motor
3	693995	Screw				32	W10131364	Belt, Drive
4	W11172310	Seal, Spill Guard	17	W10773242	Screw	33	696144	Strike, Door
5	3396795	Cover, Terminal Block	18		Cabinet	34	691366	Idler Assembly
6	3404162	Clamp, Motor (With Shield)		8530603	White	35	695737	Door, Rear
			19	98234	Clip, Ground	36		Door, Front
7	W10571724	Panel, Rear	20	8066092	Lock, Front Top		W10714515	White
8	W10575896	Clip, Spring	21		Panel, Front	37		Handle, Door
9		Plug, Sight Hole		W10664692	White		W10714516	White
	8564457	White	22	685203	Clip, Felt Pad	38	W10803476	Assembly, Seal and Bearing
10	W10569603	Switch, Door	23	337189	Clip, Hinge			
11	697773	Screw	24	3389441	Assembly, Door Catch	39	8066056	Hinge, Door (Right)
12	W10041960	Spring, Door	25	W10823580	Seal, Door		8066057	Hinge, Door (Left)
13	W10121316	Clamp, Motor Mount	26	W10869141	Cord, Power	40	342043	Screw
14	341029	Clamp, Pipe	27	342055	Screw	41	3357011	Screw
15	W10775448	Clip, Front Panel	28	W10396029	Assembly, Motor	42	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)
			29	8066184	Pulley, Motor			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	17	338906	Sensor, Radiant	31	W10714468	Bulkhead
2	W10298789	Nut, Hex	18	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	32	3397590	Roller, Support
3	3388703	Washer				33	W10359269	Shaft, Drum Roller - Right Hand Thread
4	347139	Seal, Lint Chute	19	W10754607	Thermostat, High Limit SPST (180F)	34	W10359270	Shaft, Drum Roller - Left Hand Thread
5	90767	Screw						
6	W10389567	Shield, Exhaust	20	489463	Screw	35	W10512946	Washer, Tri Ring
7	3392519	Fuse, Thermal (91C)	21	3390647	Screw	36	8578825	Bracket, Drum Light
8	3387134	Thermostat	22	339956	Seal	37	3406124	Bulb, Light
9	348197	Washer	23	W11032820	Bracket, Support	38	W10214261	Socket, Light
10	694089	Wheel, Blower	24	90296	Nut, Push On	39	3402841	Lens, Drum Light
11	8577230	Housing, Blower	25	W10757750	Assembly, Drum (Complete)	40	3390631	Screw
12	3398161	Clip, Heater Box	26	692490	Baffle, Drum (Long)			
13	343641	Screw	27	3403636	Baffle, Drum (Short)			
14	3406022	Bracket, Bulkhead Chute	28	W10856781	Seal, Rear Drum			
15	8530285	Box, Heater (96C)	29	W10219342	Screw			
16	8066049	Funnel, Burner Light	30	692526	Bearing, Ring			

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9	234826	Orifice, Burner Type 1 (Natural)	49572A		Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
4	686590	Ignitor	10	W10622159	Valve, Gas			
5	W10366705	Screw	11	W10295523	Pipe Plug			
6	343641	Screw	12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	72017	White
--	-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	799344	White (Uncut)
--	--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	279948	Kit, Dryer Repair
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing