




**SIDE BY SIDE REFRIGERATOR
Fingerprint Resistant**

MODELS:

WRSA88FIHN00 (Sunset Bronze)

WRSA88FIHZ00 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Hinge, Bottom (Freezer)	26	W10279882	Tube, Filter Inlet
	W10787932	Use & Care Guide		W11126848	Grey	27	W10279884	Tube, Filter Outlet
	W11090558	Tech Sheet	16		Hinge, Bottom (Refrigerator)	28	W10370680	Fitting, Drain
	W11099262	Energy Guide		W11084346	Grey	29	12957702	Lid, HV Box
2	2150304	Roller				30	W10887254	Control, Electronic
3	W10297485	Screw	17		Closer, Door (Refrigerator)	31		Cabinet (Not A Serviceable Part)
4	12477102	Roller		W10738911	Grey	32	W10247993	Box, Control
5	12477202	Axle, Roller	18	W10141645	Screw	33	2223388	Clip, Axle Retainer
6	981125	Rivet, Roller	19	549193	Clamp, Power Cord	34	W10341320	Assembly, Dual Water Valve
7	W10379525	Tube, Drain	20	W10257238	Cover, Unit	35	W10238092	Tube, Water
8	W10900758	Bracket, Foot	21		Filler, Wrapper	36	W10141625	Screw
9	W10141622	Bracket, Roller		12587703AP	Grey	37	W11175632	Locking Ring (1/4)
10	W10308751	Screw (Black)	22		Grille		W11175631	Locking Ring (5/16)
11	W10498992	Valve, Inlet	23	W10142234	Screw	38	W10237915	Bracket, Water Valve
12		Hinge, Top (Freezer)	24		Closer, Door (Freezer)	39	W10709916	Shim, Cam Closer
	W10901054	Grey		W10770893	Grey			
13		Hinge, Top (Refrigerator)	25	W10001250	Screw			
	W10901049	Grey						
14	W10308489	Screw (Grey)						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W10280385	Thermistor	13	W10893232	Cover, Light
2	W10735398	Filter, Water	8	W10425252	Cover, Thermistor	14	2162085	Socket, Light
3	W10300482	Cover, Water Filter	9	W10394053	Housing, Water Filter	15	W10366790	Reservoir
4	W11175955	Assembly, Air Diffuser	10	W10457603	Cover, Air Filter	16	W11125625	Lamp, LED
5	W10457601	Cover, Air Diffuser	11	W10271543	Connector, Water Tube	17	W10269099	Lens, Light
6	W10847853	Switch, Light	12	2171931	Body, Valve Tube			



REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10463648	Shelf, Snack Pan	5	W10463650	Assembly, Cover	9	W10278653	Pan, Crisper
2	W11034716	Handle, Trim	6	W10256770	Pan, Snack	10	W10256774	Pan, Meat
3	W10282883	Slide, Humidity	7	W10628713	Roller, Pan	11	W11039726	Assembly, Shelf
4	W10282880	Housing, Humidity	8	W10628712	Axle, Roller	12	W11084209	Handle, Trim


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W10628713	Roller, Pan	15	W11050578	Lens
2	W11089023	Assembly, Cover	8	W10628712	Axle, Roller	16	W10322653	Pan, Freezer Upper (Includes Items 7 & 8)
3	W11039724	Assembly, Upper Shelf	9	2155597	Socket, Light			
4	W10280386	Thermistor	10	W10847853	Switch, Light			
5	W11039725	Assembly, Lower Shelf	11	2162085	Socket, Light			
6	W10322649	Pan, Freezer Lower (Includes Items 7 & 8)	12	W11125625	Lamp, LED			
			13	W10847849	Switch, Light			
			14	W10425252	Cover, Thermistor			


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10774957	Container, Ice (Complete)	10	W11117906	Motor, Dispenser	19	W10166854	Gasket
2	W10693542	Assembly, Latch	11	W10669473	Cover, Container	20	2305382	Boot, Rubber
3	2220458	Coupling, Bottom	12	W10691248	Plate, Switch	21	W11130444	Assembly, Ice Maker
4	W10258544	Shaft, Drive	13	W10666871	Rocker, Switch			
5	W10754509	Spring, Coupling	14	W11032814	Switch, Rocker Arm			
6	W10293211	Assembly, Mounting Plate	15	W10749467	Filler, EPS Icemaker Cover			
7	2198628	Seal	16	W10646076	Assembly, Wire Jumper Switch			
8	W10291905	Gasket	17	W10400435	Gasket, Foam			
9	2212370	Washer	18	W10765378	Assembly, Motor Box			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Item 5)	6		Handle	12	W10884773	Badge
	W11038912	Sunset Bronze		W10874780	Stainless	13	W10010140	Set Screw (Silver)
	W11037738	Stainless	7	2200086	Thimble, Top			
2	W10710203	Bin, Gallon Door	8	W10460893	Screw			
3	W10296816	Screw	9		Closer, Upper Cam Door			
4		Cover, Door Stop		W10257203	Grey			
	W10789147	Grey	10	W11204458	Screw			
5		Gasket, Door	11	W10888898	Bracket, Door Stop			
	W10249916	Grey						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 8 And Dispenser Front Parts)	5	W10460893	Screw	11	W10010140	Set Screw (Silver)
	W11038923	Sunset Bronze	6	W10430639	Bin, Door	12		Cover, Door Stop
	W11037733	Stainless	7	W11204458	Screw		W10632062	Grey
2		Handle	8		Gasket, Door	13	W10323148	Cover, Wire
	W10874780	Stainless		W10249917	Grey	14	W10850872	Wire, Jumper
3	2200086	Thimble, Top	9		Closer, Upper Cam Door			
4	W10296816	Screw		W10257206	Grey			
			10	W10910405	Bracket, Door Stop			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Wall, Dispenser False	7	W10346124	Support, Ice Door	13		Tray, Drip
	W11084899	Sunset Bronze	8	4449745	Screw		W11084898	Sunset Bronze
	W10276226	Satina	9		Ring, Trim		W10276225	Satina
2		Grate, Drip Tray		W11087882	Chromium Frost	14		Cover, Front
	W10276209	Stainless	10	W10876364	Tube, Water		W10458867	Black
3	W10174827	Bracket, Ice Door	11	W11038873	Assembly, User Interface	15	W10386778	Assembly, Water Fitting
4	W10435760	Guide, Ice	12		Pad, Ice and Water			
5	W10205978	Motor, Dispenser						
6	W10781994	Assembly, Separator		W10370582	Grey			


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10251462	Scroll, Fan	8	2169142	Blade, Fan	14	W10388269	Cover, Evaporator
2	2223733	Retainer, Fan Motor	9	W10240370	Gasket, Evaporator Cover	15	W10260382	Cover, Light
3	W11040868	Duct, Upper Air	10	W10449920	Grommet, Motor	16	W11125625	Lamp, LED
4		Bi-Metal Defrost (Not Serviced)	11	W10369602	Clip, Evaporator Cover	17	2162085	Socket, Light
5	W10260384	Duct, Freezer Air	12	W10679946	Assembly, Evaporator Fan Wire (Includes Bi-Metal Defrost)	18	W10331728	Clip, Air Duct
6	W10001260	Screw						
7	W10556724	Motor, Fan	13	W10142292	Screw			

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10271541	Connector, Union	16	W10239732	Evaporator	29	2183042	Grommet
2	2225834	Blade, Fan	17	2161324	Clip, Defrost Heater			FOLLOWING PARTS NOT ILLUSTRATED
3	W10276899	Condenser	18	W10909387	Motor, Condenser Fan		978025	Valve, Access (1/4")
4	W10142255	Screw	19	W10703216	Tray, Evaporator (Includes Gasket)		978026	Valve, Access (5/16")
5	W10771114	Drier	20	W10223361	Shield, Heat		978027	Valve, Access (3/8")
6	W10171469	Screw	21	2169104	Sealer, Insulation		978029	Valve, Access (5/8")
7	W10277958	Connector, Water	22	W10679948	Assembly, Unit Wire		978030	Valve, Access (3/4")
8	W10303521	Sleeve	23	W10680691	Baseplate		876764	Valve, Access (3/16")
9	W10142287	Bolt	24	W10242407	Cord, Power			REFRIGERANT CHARGE
10	W10815861	Clip, Bottom Cover	25	W10251467	Baffle, Air			5.0 oz. (R-134A)
11	W10219381	Tube, Suction	26	W10495968	Heater, Defrost			
12	W10248621	Clip, Condenser	27	W10278140	Cover, Condenser (Bottom)			
13	W10710090	Assembly, Inverter Box	28	W10756262	Compressor			
14	2325479	Tube, Process						
15	2205813	Tie, Wire						

OPTIONAL PARTS (NOT INCLUDED)

PAIN, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque
	8171357	Graphite

PAIN, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	80051	Graphite

PAIN, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque
	8171358	Graphite

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10300794	Kit, Handle Installation
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	4318168	Sealer
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key