




## **30" BUILT-IN ELECTRIC SINGLE OVEN WITH CONVECTION**

### **MODELS:**

WOS72EC0HS01 (Stainless)

WOS72EC0HV01 (Black Stainless)


## CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|---------------------------------|
| 1                           |                 | Literature Parts                                  | 4                           | 7101P427-60     | Screw                        | 15                          | W11162063       | Gasket, Rubber                  |
|                             | W11129956       | Instructions, Installation                        | 5                           | W11200129       | Blower                       |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED |
|                             | W11097840       | Instructions, Undercounter Installation           | 6                           |                 | Skin, Control Panel          |                             | W11225368       | Harness, Main                   |
|                             | W11220323       | Guide, Use & Care                                 |                             | W10899877       | Stainless                    |                             | W11225369       | Harness, Signal                 |
|                             | W11097305       | Guide, Internet Connectivity                      |                             | W10893985       | Black Stainless              |                             | W11132989       | Harness, Door Latch             |
|                             | W11046178       | Sheet, Tech                                       | 7                           | W10318192       | Chassis, Cover Top Front 30" |                             | W10562910       | Harness, EOL                    |
|                             | W11046185       | Diagram, Wiring                                   | 8                           | 7101P426-60     | Screw                        |                             | W11233570       | Harness, Console                |
| 2                           |                 | Assembly, Control Panel (Includes Overlay)        | 9                           | W11234541       | Antenna                      |                             | 4448664         | Clamp, Conduit                  |
|                             | W11107237       | Stainless                                         | 10                          | W10655463       | Bracket, Blower (Left)       |                             | W10655464       | Bracket, Harness                |
|                             | W11107253       | Black Stainless                                   |                             | W10655462       | Bracket, Blower (Right)      |                             | W10487999       | Clip, Harness                   |
| 3                           | W11253186       | Appliance Manager, Copernicus (With Power Supply) | 11                          | W10728475       | Gasket, Rubber               |                             | 4450800         | Screw, Grounding                |
|                             |                 |                                                   | 12                          | W10904156       | Chassis, Cover Top Back 30"  |                             | 4454842         | Tie, Cable                      |
|                             |                 |                                                   | 13                          | W10864102       | Tray, Electronic             |                             |                 |                                 |
|                             |                 |                                                   | 14                          | W10655465       | Chassis, Back Divider        |                             |                 |                                 |

# OVEN PARTS



# OVEN PARTS

## Illus.

| <u>No.</u> | <u>Part No.</u> | <u>Description</u>               |
|------------|-----------------|----------------------------------|
| 1          | W10254050       | Screw                            |
| 2          | W11085298       | Tube, Vent                       |
| 3          | W11044775       | Receiver, Hinge                  |
| 4          | W10618102       | Spacer, Base                     |
| 5          | W10618131       | Latch, Motorized                 |
| 6          | W10904158       | Top, Chassis                     |
| 7          | W10734063       | Assembly, Light                  |
| 8          | W10618101       | Foot, Base                       |
| 9          | W10904163       | Deflector, Blower                |
| 10         | W10283036       | Vent, Top 30"                    |
| 11         | W10282960       | Gasket                           |
| 12         | W10616810       | Cover, Vent Exhaust              |
| 13         | W10663556       | Side, Chassis<br>(Left)          |
|            | W10318190       | Side, Chassis<br>(Right)         |
| 14         | W10904160       | Back, Chassis                    |
| 15         |                 | Liner, Oven (Not<br>Serviceable) |


## Illus.

| <u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|------------|-----------------|--------------------------------|
| 16         | W10622170       | Probe, Sensor                  |
| 17         | W10616809       | Base, Vent Exhaust             |
| 18         | 4449751         | Thermostat (TOD)               |
| 19         | W10834867       | Base, Chassis                  |
| 20         |                 | Assembly, Bottom<br>Vent       |
|            | W10351279       | Stainless                      |
|            | W10723091       | Black Stainless                |
| 21         | W10283008       | Chassis, Bottom Duct           |
| 22         |                 | Trim, Bottom Vent              |
|            | W10327377       | Stainless                      |
|            | W10921374       | Black Stainless                |
| 23         | W10213759       | Support, Air Channel           |
| 24         | W10351308       | Spacer, Chassis<br>Bottom Duct |
| 25         | W10351278       | Bumper & Screw                 |
| 26         | W10412722       | Lens, Light                    |
| 27         | 7101P426-60     | Screw                          |

## Illus.

| <u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|------------|-----------------|------------------------------------|
| 28         | W10412711       | Bulb, Light                        |
| 29         | 7101P427-60     | Screw                              |
| 30         | W10834501       | Spacers, Front                     |
| 31         | W10318196       | Duct, Chassis Back                 |
| 32         | 8285593         | Cover, Connector                   |
| 33         |                 | Cover, Side Trim                   |
|            | W10344481       | Black (Left)                       |
|            | W10344480       | Black (Right)                      |
| 34         | W10834286       | Spacer, Center                     |
| 35         | W11045086       | Receiver, Slow Close<br>Hinge      |
| 36         | W11034940       | Shield, Slow Close<br>Hinge        |
|            |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED |
|            | W10520715       | Insulation, Wrap                   |
|            | W10282944       | Insulation, Cavity                 |
|            | W10464568       | Insulation, Control<br>Knob        |


# OVEN DOOR PARTS



# OVEN DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|------------------------|-----------------------------|-----------------|--------------------|
| 1                           | W10347596       | Assembly, Window Pack       | 6                           | W11044773       | Hinge, Slow Close Door | 9                           | W10678524       | Glass, Inner       |
| 2                           | W10284285       | Spring, Door Glass Fixation | 7                           |                 | Assembly, Door Glass   | 10                          | W10284297       | Bracket, Glass     |
| 3                           | 7101P635-60     | Screw (Black)               |                             | W10866265       | Stainless              | 11                          | W10480830       | Screw              |
| 4                           | W10884775       | Nameplate                   |                             | W11028411       | Black Stainless        | 12                          | 7101P426-60     | Screw              |
| 5                           | W10709147       | Assembly, Liner             | 8                           |                 | Handle, Door           | 13                          | 7101P653-60     | Screw              |
|                             |                 |                             |                             | W10875206       | Stainless              | 14                          | W10653954       | Clip, Spring Metal |
|                             |                 |                             |                             | W10903342       | Black Stainless        | 15                          | 3196183         | Screw              |
|                             |                 |                             |                             |                 |                        | 16                          | W10319024       | Washer, Door       |

# INTERNAL OVEN PARTS





# INTERNAL OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|--------------------|
| 1                           | W10260252       | Element, Broil                | 7                           | W10546517       | Element, Bake      | 13                          | W10720084       | Screw              |
| 2                           | W11122597       | Rack, Oven                    | 8                           | W10722667       | Fan, Convection    | 14                          | W10906658       | Screw              |
| 3                           | W10318198       | Tray, Hidden Bake             | 9                           | W10631504       | Nut, Acorn (LH)    |                             |                 |                    |
| 4                           | 7101P434-60     | Screw                         | 10                          | W10631503       | Blade, Fan         |                             |                 |                    |
| 5                           | 7101P426-60     | Screw                         | 11                          | W10260248       | Ring, Element      |                             |                 |                    |
| 6                           | W10282957       | Crossbar, Hidden<br>Bake Tray | 12                          | W10359278       | Baffle, Convection |                             |                 |                    |

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|-----------------------------|-----------------|--------------------|

|       |       |
|-------|-------|
| 72017 | White |
| 72032 | Black |

## PAINT, SPRAY

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|-----------------------------|-----------------|--------------------|

|        |               |
|--------|---------------|
| 350930 | White         |
| 261900 | Citrine White |
| 830864 | Black         |

## ADHESIVE

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|-----------------------------|-----------------|--------------------|

|        |                  |
|--------|------------------|
| 482338 | Sealer, Silastic |
|--------|------------------|

## ACCESSORIES

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|-----------------------------|-----------------|--------------------|

|           |                                 |
|-----------|---------------------------------|
| 4396923   | Grid, Broiler Pan and           |
| W10275756 | Cleaner, Granite                |
| W10123240 | Rack, Broiler Pan & Roasting    |
| W10355049 | Wipes, Stainless Steel Cleaning |
| W10355016 | Cleaner, Stainless Steel        |
| W10745649 | Rack, Sliding                   |