


AK1200CS
AK1200CBS
AK1200CB
AK1200CW
AK1236CS
AK1236CBS
AK1236CB
AK1236CW



AK12xxCx

| Ref # | Part # | Description | Qty. |
|--------------|---------------|---|-------------|
| 1 | 54050009 | Rectangular Starting Collar | 1 |
| 2 | 54050083 | Rectangular Cover Plate | 1 |
| 3 | 54050065 | 7 Inch Round Starting Plate | 1 |
| 4 | 54050034 | Rectangular Starting Plate | 1 |
| 5 | 11030126 | Electrical Wires | 1 |
| 7 | 54200011 | Electrical Junction Box | 1 |
| 8 | 50140196 | Top Recirculating Cover Panel (Stainless) | 1 |
| 8 | 50140197 | Top Recirculating Cover Panel (Black Stainless) | 1 |
| 8 | 50140198 | Top Recirculating Cover Panel (Black) | 1 |
| 8 | 50140199 | Top Recirculating Cover Panel (White) | 1 |
| 9 | 54140321 | Switch Bracket | 1 |
| 10 | 11000156 | Switch Assembly | 1 |
| 11 | 54140060 | Motor Isolator | 2 |
| 12 | 12120096 | Left Motor | 1 |
| 13 | 12120097 | Right Motor | 1 |
| 14 | 54250011 | Left Blower Wheel | 1 |
| 15 | 54250013 | Right Blower Wheel | 1 |
| 16 | 50220010 | Residue Pan | 2 |
| 17 | 50200012 | Aluminum Mesh Filter | 2 |
| 18 | 50120023 | Spacer Panel (AK1236CS) | 2 |
| 18 | 50120156 | Spacer Panel (AK1236CBS) | 2 |
| 18 | 50120024 | Spacer Panel (AK1236CB) | 2 |
| 18 | 50120025 | Spacer Panel (AK1236CW) | 2 |
| 20 | 50140200 | Internal Panel (30") | 1 |
| 20 | 50140201 | Internal Panel (36") | 1 |
| 21 | 50110354 | Light Panel (AK1200CS) | 1 |
| 21 | 50110355 | Light Panel (AK1200CBS) | 1 |
| 21 | 50110356 | Light Panel (AK1200CB) | 1 |
| 21 | 50110357 | Light Panel (AK1200CW) | 1 |
| 21 | 50110358 | Light Panel (AK1236CS) | 1 |
| 21 | 50110359 | Light Panel (AK1236CBS) | 1 |

| | | | |
|-----------|----------|------------------------|---|
| 21 | 50110360 | Light Panel (AK1236CB) | 1 |
| 21 | 50110361 | Light Panel (AK1236CW) | 1 |
| 22 | 12050009 | Capacitor | 1 |
| 23 | Z0B0047 | LumiLight LED, 6W | 2 |
| 24 | 05000169 | Hardware Packet | 1 |

SEP21.0101