



CCA-E30ASX
 CCA-E36ASX
 CCA-E48ASX



CCA-E30ASX, CCA-E36ASX, CCA-E48ASX

Ref #	Part #	Description	Qty.
1	54050009	Collar, Starting, 3 1/4" x 10"	1
3	54140028	Bracket, Motor	2
4	50210004	Filter, Baffle (48" x 3)	2
5	50120028	Panel, Spice Shelf Side, Right	1
6	50120029	Panel, Spice Shelf Side, Left	1
7	54050052	Plate, 6" Round	1
8	52170034	Cover Plate, Controls	1
9	56240012	Cover Plate, Switch Interior	1
10	54050049	Cover Plate, Top	1
11	54120008	Bracket, Spice Door	2
12	50110045	Panel, Light (CCA-E30ASX)	2
12	50110046	Panel, Light (CCA-E36ASX)	2
12	50110047	Panel, Light (CCA-E48ASX)	4
13	50100004	Panel, Switch (CCA-E30ASX)	1
13	50100005	Panel, Switch (CCA-E36ASX)	1
13	50100006	Panel, Switch (CCA-E48ASX)	1
14	50140071	Panel, Spice Shelf (CCA-E30ASX)	1
14	50140072	Panel, Spice Shelf (CCA-E36ASX)	1
14	50140076	Panel, Spice Shelf (CCA-E48ASX)	1
15	50330003	Rod, Spice Door (CCA-E30ASX)	1
15	50330004	Rod, Spice Door (CCA-E36ASX)	1
15	50330005	Rod, Spice Door (CCA-E48ASX)	1
16	54140036	Bracket, Filter (CCA-E30ASX)	1
16	54140037	Bracket, Filter (CCA-E36ASX)	1
16	54140041	Bracket, Filter (CCA-E48ASX)	1
17	50140073	Panel, Interior Cover (CCA-E30ASX)	1
17	50140074	Panel, Interior Cover (CCA-E36ASX)	1
17	50140077	Panel, Interior Cover (CCA-E48ASX)	1
19	54050050	Collar, 8" Round	1
20	52170033	Housing, Switch Board	1
21	56200051	Box, Component	1
22	56210024	Cover, Component Box	1
23	50400007	Button, Switch	1
24	52110011	Membrane	1
25	50300041	Door, Spice (CCA-E30ASX)	1
25	50300042	Door, Spice (CCA-E36ASX)	1
25	50300043	Door, Spice (CCA-E48ASX)	1
30	11030028	Wires, Electrical	1
33	56220021	Gasket	1
44	ZOB-0020	Bulb, Halogen 50W GU-10 (48" x 4)	2

45	54190002	Plate, Light Socket (48" x 4)	2
46	56250002	Insulator, Light Socket (48" x 4)	2
47	54200011	Junction Box	1
48	56200049	Housing, Light Socket (48" x 4)	2
49	54050043	Transition Adaptor, 6" to 3 1/4" x 10"	1
50	56200050	Cover, Switch Housing	1
56	54050053	Plate, Wire	1
62	11030030	Cable, Harness, External Blower	1
64	12100034	Socket, Light, Right (48" x 2)	1
65	12100035	Socket, Light, Left	1
68	01090005	Screw, M6 x 20mm	2
69	01090006	Screw, M6 x 29mm	4
70	11010028	Board, Switch	1
71	11010031	Board, Control	1
72	12170002	Fuse, 4A, 250V	1
75	56240010	Spacer, Rubber	2
76	01020016	Screw, SS Cariage x 1/2"	2
80	54140029	Filter Spring Clip	5
81	50320021	Rail, Spice Door (CCA-E30ASX)	1
81	50320022	Rail, Spice Door (CCA-E36ASX)	1
81	50320025	Rail, Spice Door (CCA-E48ASX)	1
82	50320023	Rail, Spice Shelf (CCA-E30ASX)	1
82	50320024	Rail, Spice Shelf (CCA-E36ASX)	1
82	50320026	Rail, Spice Shelf (CCA-E48ASX)	1
84	54140039	Piston	2
85	54140038	Holder, Bottom Piston	2
86	56210025	Cover, Piston Holder	8
88	54140040	Holder, Top Piston	2
91	12100036	Socket, Light (CCA-E48ASX)	1
92	12100037	Socket, Light (CCA-E48ASX)	1
83	05000047	Hardware Packet	1
83-1	01650001	Screw, 3/16" x 3/8"	4
83-2	01070009	Screw, M4 x 6mm	4
83-3	01070007	Screw, M4 x 16mm	4
83-4	01090001	Screw, M6 x 1"	4
83-5	01090002	Screw, M6 x 1 1/2"	4
83-6	01090003	Screw, M6 x 2"	4
83-7	15000002	Cap, Wire	3
83-8	56170001	Zip Tie Fastener	1
83-9	54050054	Zip Tie Fastener Plate	1
83-10	01060001	Screw, M3.5 x 10mm	4
83-11	01070010	Screw, M4 x 8mm	22
83-12	00100014	Allen Wrench	1
83-13	15000004	Suction Cup	1