


#### PRODUCT MODEL NUMBERS

#### MEDB800V, MEDB850W

**Electrical:** To supply the required 3 or 4 wire, single phase, 120/240-volt, 60-Hz, AC-only electrical supply (or 3 or 4 wire, 120/208 volt electrical supply, if specified on the serial/rating plate) on a separate 30-amp circuit, fused on both sides of the line. A time-delay fuse or circuit breaker is recommended. Connect to an individual branch circuit. Do not have a fuse in the neutral or grounding circuit. Do not use an extension cord.

**Exhaust venting:** Exhaust your dryer to the outside. 4" (102 mm) diameter heavy metal vent and clamps must be used. Do not use plastic or metal foil vent. Exhaust hood must be at least 12" (305 mm) from the ground or any object that may be in the path of the exhaust.

### PRODUCT DIMENSIONS




\*Most installations require a minimum 5" (127 mm) clearance behind the dryer for the exhaust vent with elbow.

### RECESSED AREA AND CLOSET INSTALLATION

The following spacing dimensions are recommended for this dryer. This dryer has been tested for spacing of 0" (0 cm) clearance on the sides and rear.

For closet installation with a door, minimum ventilation openings in the top and bottom of the door are required.


Louvered doors with equivalent air openings are acceptable.



- A. Recessed area
- B. Side view closet or confined area
- C. Closet door with vents
- \* Required spacing

## **EXHAUST VENTING**

# Vent system chart



Angled style

- Select the route that will provide the straightest and most direct path outdoors. Plan the installation to use the fewest number of elbows and turns. When using elbows or making turns, allow as much room as possible. Bend vent gradually to avoid kinking. Use the fewest 90° turns possible.
- 2. Determine vent length.

The maximum length of the exhaust system depends upon:

- The type of vent (rigid metal or flexible metal).
- The number of elbows used.
- Type of hood.

See the exhaust vent length chart that matches your hood type for the maximum vent lengths you can use.

3. Determine the number of elbows you will need.

**IMPORTANT:** Do not use vent runs longer than specified in the Vent Length Chart.

Number of 90° turns or elbows	Type of vent	Box or Louvered hoods	Angled hoods
0	Rigid metal	64 ft (20 m)	58 ft (17.7 m)
1	Rigid metal	54 ft (16.5 m)	48 ft (14.6 m)
2	Rigid metal	44 ft (13.4 m)	38 ft (11.6 m)
3	Rigid metal	35 ft (10.7 m)	29 ft (8.8 m)
4	Rigid metal	27 ft (8.2 m)	21 ft (6.4 m)