KitchenAid [®] Warming Drawer

PRODUCT MODEL NUMBERS

KEWS105S KEWS145S KEWS175S


ELECTRICAL:

A 120 volt, 60 Hz., AC only, 15-amp fused, electrical circuit is required. A time-delay fuse or circuit breaker is also recommended. It is recommended that a separate circuit serving only this warming drawer be provided.

Electrical supply outlet should be located in the rear wall on the upper right-hand side of the cutout or in an adjacent cabinet. The outlet must be recessed. If the electrical outlet is located in an adjacent cabinet, a 1%" (3.5 cm) minimum diameter hole should have been drilled in the back of the cutout or support surface to pass the power supply cord through to the outlet.


Warming drawer support surface must be solid, level and flush with bottom of cabinet cutout.

OVERALL DIMENSIONS




WARMING DRAWER SIZE	OVERALL WIDTH (A)	RECESSED WIDTH (B)	RECESSED HEIGHT (C)
24"	23 ¾"	22 ¼"	9"
(61 cm)	(60.3 cm)	(56.5 cm)	(22.9 cm)
27"	26 ¾"	25 ¼"	9"
(68.6 cm)	(67.9 cm)	(64.1 cm)	(22.9 cm)
30"	29 ¾"	28 ¼"	9"
(76.2 cm)	(75.6 cm)	(71.8 cm)	(22.9 cm)

Cabinet Side View



WARMING	CUTOUT	MIN. CABINET
DRAWER SIZE	WIDTH (A)	WIDTH (B)
24"	22 ½"	24"
(61 cm)	(57.1 cm)	(61 cm)
27"	25 ½"	27"
(68.6 cm)	(64.8 cm)	(68.6 cm)
30"	28 ½"	30"
(76.2 cm)	(72.4 cm)	(76.2 cm)

Cabinet Front View



Warming drawer can be installed as an indoor single or double installation or installed under a single oven. Two warming drawers under a single oven are shown.

Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice. Dimensions are for planning purposes only. For complete details, see Installation Instructions packed with product. Specifications subject to change without notice.